

Operation & Maintenance Manual

Self-Propelled
Articulating Boom Lifts

BA16J-AWD

BA14J-AWD



Dingli
Machinery

Part Number: SM0408111A

Third Edition, April 2018 Printing

Table of Contents

| | |
|--|-----|
| Foreword | 1 |
| Section 1 Safety Precaution | |
| 1.1 General..... | 1-1 |
| 1.2 Safety Alert Symbols and Safety Signal Words | 1-1 |
| 1.3 Safety Precaution | 1-2 |
| 1.3.1 Operator Training and Knowledge | 1-2 |
| 1.3.2 Workplace Inspection..... | 1-2 |
| 1.3.3 Machine Inspection..... | 1-3 |
| 1.4 Operation..... | 1-3 |
| 1.4.1 General..... | 1-3 |
| 1.4.2 Trip and Fall Hazards | 1-4 |
| 1.4.3 Electrocution Hazards | 1-5 |
| 1.4.4 Tipping Hazards | 1-6 |
| 1.4.5 Crushing and Collision Hazards | 1-7 |
| 1.5 Towing, Lifting and Hauling | 1-8 |
| 1.6 Additional Hazards / Safety | 1-9 |
| Section 2 Specification | |
| 2.1 Machine Specification | 2-1 |
| 2.1.1 BA14J-AWD Machine Specification..... | 2-1 |
| 2.1.2 BA16J-AWD Machine Specification..... | 2-2 |
| 2.2 Performance Specification | 2-3 |
| 2.3 Hydraulic System Specification | 2-4 |
| 2.4 Kubota V2403-M Engine Specification | 2-6 |
| 2.5 Perkins 404D-22 Engine Specification | 2-7 |
| 2.6 Bolt Torque Specification..... | 2-8 |
| Section 3 User responsibility, Machine Preparation and Inspection | |
| 3.1 Personnel Training | 3-1 |
| 3.1.1 Operator Training | 3-1 |
| 3.1.2 Training Supervision | 3-1 |

| | |
|--|------|
| 3.1.3 Operator Responsibility..... | 3-1 |
| 3.2 Preparation, Inspection and Maintenance | 3-2 |
| 3.2.1 General..... | 3-2 |
| 3.2.2 Preparation for Use..... | 3-2 |
| 3.2.3 Delivery and Frequent Inspection..... | 3-3 |
| 3.2.4 Daily Walk-around Inspection..... | 3-6 |
| 3.2.5 Daily Function Check..... | 3-10 |
| 3.3 Oscillating Axle Lockout Test (If Equipped)..... | 3-12 |
| Section 4 Machine Controls and Indicators | |
| 4.1 General..... | 4-1 |
| 4.2 Controls and Indicators | 4-1 |
| 4.2.1 Ground Control Station..... | 4-1 |
| 4.2.2 Platform Control Station | 4-7 |
| 4.2.3 The Multi-Function Gauge | 4-12 |
| 4.2.4 The Control Unit Display Panel | 4-13 |
| 4.3 Tilt Alarm Warning..... | 4-15 |
| 4.4 Footswitch/Enable Indicator | 4-16 |
| 4.5 Placards and Decals | 4-16 |
| Section 5 Operation Instruction | |
| 5.1 Description..... | 5-1 |
| 5.2 Operating Characteristics and Limitations | 5-2 |
| 5.3 Engine Operation..... | 5-5 |
| 5.4 Traveling (Driving) Operation | 5-6 |
| 5.5 Steering Operation..... | 5-7 |
| 5.6 Platform Operation..... | 5-7 |
| 5.7 Turntable Swinging Operation | 5-7 |
| 5.8 Boom Operation..... | 5-8 |
| 5.9 Jib Operation | 5-10 |
| 5.10 Auxiliary Pump Operation..... | 5-10 |
| 5.11 Oscillating Axle Lockout Test (If Equipped) | 5-11 |
| 5.12 Shut Down and Parking | 5-11 |
| 5.13 Lifting and Tie Down | 5-11 |

5.14 Towing Operation..... 5-13

Section 6 Emergency Procedures

6.1 General..... 6-1

6.2 Emergency Towing Procedures 6-1

6.3 Emergency Controls and Their Locations..... 6-2

 6.3.1 Power/Emergency Stop Switches 6-2

 6.3.2 Ground Control Station 6-2

 6.3.3 Auxiliary Power..... 6-2

6.4 Emergency Operation 6-3

 6.4.1 Use of Ground Controls 6-3

 6.4.2 Operator Unable to Control Machine 6-3

 6.4.3 Platform or Boom Caught Overhead 6-3

 6.4.4 Post Incident Inspection and Repair..... 6-3

6.5 Incident Notification..... 6-4

Section 7 General Maintenance

7.1 General..... 7-1

7.2 Lubrication Specification 7-1

7.3 Lubrication Diagram..... 7-1

7.4 Operator Maintenance 7-3

 7.4.1 Wheel Bearings 7-3

 7.4.2 Lubrication for the Swing Bearing and Worm Gear..... 7-3

 7.4.3 Test and Replace the Hydraulic Oil..... 7-4

 7.4.4 Replace the Hydraulic Filters 7-6

 7.4.5 Replace the Engine Oil 7-7

 7.4.6 Replace the Engine Fuel Filter 7-7

 7.4.7 Replace the Water Separator..... 7-8

 7.4.8 Tires & Wheels Maintenance..... 7-9

 7.4.9 Battery Maintenance7-11

Section 8 Schematics

8.1 General..... 8-1

8.2 Troubleshooting 8-1

| | |
|--|-----|
| 8.3 Hydraulic Circuit Checks | 8-1 |
| 8.3.1 Hydraulic Schematics..... | 8-2 |
| 8.3.2 Electric Schematics..... | 8-5 |
| Section 9 Inspection and Repair Log | |
| 9.1 Inspection and Repair Log | 9-1 |

Foreword

We are very appreciated for your interesting with Dingli machine and choosing it for your application. Our priority above all is you can use the machine safely for your application and you can benefit from the Dingli machine mostly. For these reason we hope you can:

1. Comply with employer, job site and local governmental rules.
2. The manual provides very important information about the machine. It is essential to the owner or the operator who use the machine. So we strongly recommend that you should read the manual thoroughly before attempting to do anything with the machine, so as to understand and follow the instruction or other information in the manual, especially the safety information.
3. Dingli cannot anticipate every possible circumstance that might involve a potential hazard. The warnings in this publication and on the product are, therefore, not all inclusive. If a tool, procedure, work method or operating technique that is not specifically recommended by Dingli is used, you must satisfy yourself that it is safe for you and for others. You should also ensure that the product will not be damaged or be made unsafe by the operation, lubrication, maintenance or repair procedure that you choose.
4. The information, specifications, and illustrations in this publication are on the basis of information that was available at the time that the publication was written. Due to the continuous improvements, Dingli reserve the rights to make the specifications changes without prior notification. Please contact with Dingli dealers or Dingli distributors to obtain the complete and most current information.
5. Any one who read the manual or used the machine, is encouraged to notify Dingli Machinery Co, Ltd of any errors or send in suggestions for improvement. All communications will be carefully considered for future printings of this and other manuals, certainly if you have any question about the machine, please contact with our team by dialing technical support phone, sending email, or any methods you want, etc. Our contact information as bellow:

If you are in China Mainland, Please contact with:

Zhejiang Dingli Machinery Co.,Ltd. Domestic Office:

Phone: +86 572 8681766

Fax: +86 572 8681700

Email: sales@cndingli.com

If you are out of the China Mainland, Please contact with:

Zhejiang Dingli Machinery Co.,Ltd. International Office:

Phone: +86 572 8681688

Fax: +86 572 8681690

Email: export@cndingli.com

Safety Precaution

Section 1

1.1 General

This section prescribes the proper and safe practices for major areas of machine usage. In order to promote proper usage of the machine, it is mandatory that a daily routine be established based on instructions given in this section. A maintenance program must also be established by a qualified person and must be followed to ensure that the machine is safe to operate.

The owner/user/operator of the machine should not accept operating responsibility until this manual has been read and understood, and operation of the machine, under the supervision of an experienced and qualified person, has been completed. If there is a question on application and/or operation, Dingli Machinery Co.,Ltd. should be consulted.

Most accidents that involve product operation, maintenance and repair are caused by failure to observe basic safety rules or precautions. An accident can often be avoided by recognizing potentially hazardous situations before an accident occurs. A person must be alerted to potential hazards. This person should also have the necessary training, skills, and tools to perform these functions properly.

Improper operation, lubrication, maintenance or repair of this product can be dangerous and could result in injury or death. Do not operate or perform any lubrication, maintenance or repair on this product, until you have read and understood the operation, lubrication, and maintenance & repair information.

1.2 Safety Alert Symbols and Safety Signal Words



This Safety Alert Symbol is used to call attention to POTENTIAL HAZARDS, if these hazard warnings are not heeded, bodily injury or death could occur to you or to other persons. The hazards are identified by the "Safety Alert Symbol" and followed by a "Signal Word" such as DANGER, WARNING" or CAUTION, which have been inserted throughout this manual to emphasize these areas. They are defined as follows:

! DANGER

Indicate an IMMEDIATELY DANGEROUS SITUATION, which if not avoided, WILL RESULT IN SERIOUS INJURY or DEATH. This decal will have a red background

⚠ WARNING

Indicate a potentially HAZARDOUS SITUATION, which if not been avoided, Could RESULT IN SERIOUS INJURY OR DEATH. This decal will have an orange background.

⚠ CAUTION

Indicate a potentially HAZARDOUS SITUATION, which if not avoided, may RESULT IN minor or moderate INJURY. This decal will have a yellow background.

NOTICE

Indicate a potentially hazardous situation, which if not avoided, could result in property damage, this decal have a blue background.

1.3 Safety Precaution

⚠ WARNING

FAILURE TO COMPLY WITH THE SAFETY PRECAUTIONS LISTED IN THIS MANUAL COULD RESULT IN MACHINE DAMAGE, PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.



1.3.1 Operator Training and Knowledge

- Read and understand this manual before operating the machine.
- Read, understand, and obey all **DANGERS, WARNINGS, CAUTIONS**, and operating instructions on the machine and in this manual.
- Do not operate this machine until complete training is performed by authorized persons. Only authorized and qualified personnel can operate the machine.
- Use the machine in a manner which is within the scope of its intended application.
- All operating personnel must be familiar with the emergency controls and emergency operation of the machine as specified in this manual.
- Read, understand, and obey all applicable employer, local, and governmental regulations as they pertain to operation of the machine.

1.3.2 Workplace Inspection

- The operator is to take safety measures to avoid all hazards in the work area prior to machine operation.
- Do not operate or raise the platform while on trucks, trailers, railway cars, floating vessels, scaffolds or other equipment.

- Do not operate the machine in hazardous environments unless approved for that purpose by Dingli.
- Be sure that the ground conditions are able to support the maximum load shown on the decals located on the machine.
- This machine can be operated in temperatures of -20°C to 40°C. Consult Dingli for operation outside this range.

1.3.3 Machine Inspection

- Before machine operation, perform inspections and functional checks. Refer to **Section 3** of this manual for detailed instructions.
- Do not operate this machine until it has been serviced and maintained according to requirements specified by the manufacture.
- Be sure the footswitch and all other safety devices are operating properly. Modification of these devices is a safety violation.

⚠ WARNING

MODIFICATION OR ALTERATION OF AN AERIAL WORK PLATFORM SHALL BE MADE ONLY WITH WRITTEN PERMISSION FROM THE MANUFACTURER.

- Do not operate any machine on which safety or instruction placards or decals are missing or illegible.
- Avoid any buildup of debris on the platform floor. Keep mud, oil, grease, and other slippery substances from footwear and platform floor.



1.4 Operation


1.4.1 General

- Do not use the machine for any purpose other than positioning personnel, their tools, and equipment.
- Never operate a machine that is not working properly. If a malfunction occurs, shut down the machine for troubleshooting.
- Never slam a control switch or lever through neutral to an opposite direction. Always return switch to neutral and stop before moving the switch to the next function. Operate controls with slow and even pressure. Hydraulic cylinders should never be left fully extended or fully retracted before shutdown or for long periods of time.
- Do not allow personnel to tamper with or operate the machine from the ground with personnel in the platform, except in an emergency.
- Do not carry materials directly on platform railing.


- When two or more persons are in the platform, the operator shall be responsible for all machine operations.
- Always ensure that power tools are properly stowed and never left hanging by their cord from the platform work area.
- Supplies or tools which extend outside the platform are prohibited unless approved.
- When driving, always position boom over rear axle in line with the direction of travel. Remember, if boom is over the front axle, steer and drive functions will be reversed.
- Do not assist a stuck or disabled machine by pushing, pulling, or by using boom functions. Only pull the unit from the tie-down lugs on the chassis.
- Do not place boom or platform against any structure to steady the platform or to support the structure.
- Stow boom and shut off all power before leaving machine.

1.4.2 Trip and Fall Hazards

- During operation, occupants in the platform must wear a full body harness with a lanyard attached to an authorized lanyard anchorage point. Attach only one (1) lanyard per lanyard anchorage point.
- Before operating the machine, make sure all gates are closed and fastened in their proper position.




- Keep both feet firmly positioned on the platform floor at all times. Never use ladders, boxes, steps, planks, or similar items on platform to provide additional reach.



- Never use the boom assembly to enter or leave the platform.
- Use extreme caution when entering or leaving platform. Be sure that the boom is fully lowered. It may be necessary to telescope out to position the platform closer to the ground for entry/exit. Face the machine, maintain “three point contact” with the machine, using two hands and one foot or two feet and one hand during entry and exit.

1.4.3 Electrocuting Hazards

- This machine is not insulated and does not provide protection from contact or proximity to electrical current.



- Maintain distance from electrical lines, apparatus, or any energized (exposed or insulated) parts according to the Minimum Approach Distance (MAD) as shown in Table 1.1

Table 1-1. Minimum Approach Distances (M.A.D.)

| Voltage Range (Phase to Phase) | MINIMUM APPROACH DISTANCE in Feet (Meters) |
|--------------------------------|--|
| 0 to 50 KV | 10 (3) |
| Over 50KV to 200 KV | 15 (5) |
| Over 200 KV to 350 KV | 20 (6) |
| Over 350 KV to 500 KV | 25 (8) |
| Over 500 KV to 750 KV | 35 (11) |
| Over 750 KV to 1000 KV | 45 (14) |

NOTE: This requirement shall apply except where employer, local or governmental regulations are more stringent.

- Allow for machine movement and electrical line swaying.
- Maintain a clearance of at least 10 ft. (3m) between any part of the machine and its occupants, their tools, and their equipment from any electrical line or apparatus carrying up to 50,000 volts. One foot additional clearance is required for every additional 30,000 volts or less.
- The minimum approach distance may be reduced if insulating barriers are installed to prevent contact, and the barriers are rated for the voltage of the line being guarded. These barriers shall not be part of (or attached to) the machine. The minimum approach distance shall be

reduced to a distance within the designed working dimensions of the insulating barrier. This determination shall be made by a qualified person in accordance with the employer, local, or governmental requirements for work practices near energized equipment.

⚠ DANGER


DO NOT MANEUVER MACHINE OR PERSONNEL INSIDE PROHIBITED ZONE (MAD). ASSUME ALL ELECTRICAL PARTS AND WIRING IS ENERGIZED UNLESS KNOWN OTHERWISE.

1.4.4 Tipping Hazards

- The user should be familiar with the surface before driving. Do not exceed the allowable side slope and grade while driving.
- Do not elevate platform or drive with platform elevated while on a sloping, uneven, or soft surface.
- Before driving on floors, bridges, trucks, and other surfaces, check allowable capacity of the surfaces.



- Never exceed the maximum platform capacity. Distribute loads evenly on platform floor.



- Do not raise the platform or drive from an elevated position unless the machine is on firm, level and smooth surfaces.
- Keep the chassis of the machine at least 2 ft. (0.6m) from holes, bumps, drop-offs, obstructions, debris, concealed holes, and other potential hazards on the floor/surface.
- Do not push or pull any object with the boom.
- Never attempt to use the machine as a crane.
- Do not tie off machine to any adjacent structure.
- Do not operate the machine when wind conditions exceed 28 mph (12.5 m/s).



- Do not increase the platform size with unauthorized deck extensions or attachments.
- If boom assembly or platform is in a position that one or more wheels are off the ground, all persons must be removed before attempting to stabilize the machine. Use cranes, forklift trucks, or other appropriate equipment to stabilize machine and remove personnel.

1.4.5 Crushing and Collision Hazards

- Approved head gear must be worn by all operating and ground personnel.
- Check work area for clearances overhead, on sides, and bottom of platform when lifting or lowering platform, and driving.




- During operation, keep all body parts inside platform railing.
- Use the boom functions, not the drive function, to position the platform close to obstacles.
- Always post a lookout when driving in areas where vision is obstructed.

- Keep non-operating personnel at least 6 ft. (1.8m) away from machine during all driving and swing operations.
- Limit travel speed according to conditions of ground surface, congestion, visibility, slope, location of personnel, and other factors which may cause collision or injury to personnel.
- Be aware of stopping distances in all drive speeds. When driving in high speed, switch to low speed before stopping.
- Travel grades in low speed only.
- Do not use high speed drive in restricted or close quarters or when driving in reverse.



- Exercise extreme caution at all times to prevent obstacles from striking or interfering with operating controls and persons in the platform.
- Be sure that operators of other overhead and floor level machines are aware of the aerial work platform's presence. Disconnect power to overhead cranes.
- Warn personnel not to work, stand, or walk under a raised boom or platform. Position barricades on floor if necessary.



1.5 Towing, Lifting and Hauling

- Never allow personnel in platform while towing, lifting, or hauling.
- This machine should not be towed, except in the event of emergency, malfunction, power failure, or loading/unloading. Refer to the Emergency Procedures section of this manual for emergency towing procedures.
- Ensure boom is in the stowed position and the turntable locked prior to towing, lifting or hauling. The platform must be completely empty of tools.

- When lifting machine, lift only at designated areas of the machine. Lift the unit with equipment of adequate capacity.
- Refer to the Machine Operation section of this manual for lifting information.

1.6 Additional Hazards / Safety

- Do not use machine as a ground for welding.
- When performing welding or metal cutting operations, precautions must be taken to protect the chassis from direct exposure to weld and metal cutting spatter.
- Do not refuel the machine with the engine running.
- Battery fluid is highly corrosive. Avoid contact with skin and clothing at all times.
- Charge batteries only in a well ventilated area.

Specification

Section 2

2.1 Machine Specification

2.1.1 BA14J-AWD Machine Specification

| | |
|--------------------------------|----------------|
| Stowed Dimension | |
| Length(transport position) | 5.15m |
| Overall Length | 6.94m |
| Overall Width | 2.3m |
| Overall Height | 2.48m |
| Machine Gross Weight | 7430kg |
| Ground Clearance | 0.30m |
| Operation Dimension | |
| Maximum Platform Height | 14m |
| Maximum Working Height | 16m |
| Maximum Up and Over Height | 7.67m |
| Maximum Horizontal Reach | 7.47m |
| Main Boom Up Angle | 75° |
| Main Boom Down Angle | -10° |
| Maximum Turntable Tail swing | 0 |
| Wheelbase | 2.2m |
| Minimum Turning Circle Inside | 2.85m |
| Minimum Turning Circle Outside | 3.46m |
| Turntable Rotation | 360 continuous |
| Platform Rotation | 180° |
| Tire and Wheels | |
| Solid Tire and Wheel | |
| Size | 33*12-20 |
| Outer Diameter | 838mm |

| | |
|---|---------|
| Width | 287mm |
| Weight | 194kg |
| Foam Filled Tire | |
| Size | 12*16.5 |
| Outer Diameter | 818mm |
| Width | 305mm |
| Weight | 227kg |
| Airborne Noise Emission: | |
| Maximum Sound Level at 1.5 Meters From the Engine | 81.3db |

2.1.2 BA16J-AWD Machine Specification

| | |
|--------------------------------|----------------|
| Stowed Dimension | |
| Length (Transport Position) | 5.8m |
| Overall Length | 7.8m |
| Overall Width | 2.3m |
| Overall Height | 2.48m |
| Machine Gross Weight | 7835kg |
| Ground Clearance | 0.30m |
| Operation Dimension | |
| Maximum Platform Height | 16m |
| Maximum Working Height | 18m |
| Maximum Up and Over Height | 8.45m |
| Maximum Horizontal Reach | 8.85m |
| Main Boom Up Angle | 75° |
| Main Boom Down Angle | -10° |
| Maximum Turntable Tail swing | 0 |
| Wheelbase | 2.2m |
| Minimum Turning Circle Inside | 2.85m |
| Minimum Turning Circle Outside | 3.46m |
| Turntable Rotation | 360 continuous |
| Platform Rotation | 180° |

| Tire and Wheels | |
|---|----------|
| Solid Tire and Wheel | |
| Size | 33*12-20 |
| Outer Diameter | 838mm |
| Width | 287mm |
| Weight | 194kg |
| Foam Filled Tire | |
| Size | 12*16.5 |
| Outer Diameter | 818mm |
| Width | 305 |
| Weight | 227kg |
| Airborne Noise Emission: | |
| Maximum Sound Level at 1.5 Meters From the Engine | 81.3db |

2.2 Performance Specification

| | |
|-------------------------|--|
| Driving Speed | |
| Boom Stowed, high range | 6km/h |
| Boom Raised or Extended | 1.1km/h |
| Grade ability (Stowed) | 40% for 4*4 drive 30% for 4*2 drive |
| Main Lift Up | 24-28 sec |
| Main Lift Down | 20-24 sec |
| Swing Right & Left | 80-90 sec |
| Telescope Extend Out | 15-20 sec |
| Telescope Retract In | 9-15 sec |
| Platform Rotate R & L | 25-32 sec |
| Jib Up | 20-31 sec |
| Jib Down | 19-25 sec |
| Lower and Mid Boom Up | 30-38 sec |
| Lower and Mid Boom Down | 22-28 sec |

Machine Orientation When Doing Speed Tests

Lift: Boom Retracted. Telescope Retracted. Lift Up, Record Time, Lift Down, Record Time.

Swing: Boom at Full Elevation. Telescope Retracted. Swing the Turntable to the end stop. Swing the Opposite Direction, Record Time.

Telescope: Boom at Full Elevation; Telescope Retracted; Telescope Out, Record Time. Telescope In, Record Time.

Drive: Test to be done on a smooth level surface. Drive Select Switch should be set at 2WD High Engine. Start approximately 25 ft. (7.62 m) from starting point so that the unit is at maximum speed when starting the test. Results should be recorded for a 200 ft. (60.96 m) course. Drive Forward, record time. Drive Reverse, Record Time.

Drive (Above Horizontal): Test should be done on a smooth level surface. Drive Select Switch should be set to 2WD High Engine. The Platform Speed Knob should be selected out of the creep speed. This verifies that the switches are working when the boom is above horizontal. Results should be recorded for a 50 ft. course. Drive Forward, Record Time. Drive Reverse, Record Time.

Platform Rotate: Platform level and completely rotated one direction. Rotate the opposite direction, Record Time. Rotate the other direction, Record Time.

Articulating Jib: Platform level and centered with the boom. Start with the Jib down. Jib Up, Record Time. Jib Down, Record Time.

Lower Lift: Upper Boom horizontal. Telescoped In. Lower Lift Up, Record Time. Lower Lift Down, Record Time.

Test Notes

1. Stop watch should be started with the function, not with the controller or switch.
2. Drive test results reflect 12x16.5 tires.
3. All speed tests are run from the platform. These speeds do not reflect the ground control operation.
4. The platform speed Toggle Switch control must be at full speed
5. Function speeds may vary due to cold, thick hydraulic oil. Test should be run with the oil temperature above 100° F (38° C).
6. Some flow control functions may not work with the speed knob clicked into the creep position.

2.3 Hydraulic System Specification

| | |
|-----------------------------|---|
| Drive Pump | |
| Type | Bi-directional Variable Displacement piston pump, EDC control |
| Displacement per revolution | 28cc for 4*2 drive 46cc for 4*4 drive |
| Maximum Peak Pressure | 290 bar |

| | |
|---|---------------------------------------|
| Maximum Continuous Working Pressure | 250 bar |
| Hydraulic Filter | 10um |
| Drive Motor | |
| Type | Two Speed Variable Displacement Motor |
| Displacement per revolution | 38/14.36 cc |
| Rated Working Pressure | 250 bar |
| Function Pump | |
| Type | Gear Pump |
| Rated Working Pressure | 240 bar |
| Displacement per revolution | 14cc |
| Hydraulic Tank Return Filter | 10um |
| Dive Manifold | |
| Motor Shift/Brake Release Pressure | 20 bar |
| Function Manifold | |
| Function Main Relief Pressure, used for Main Boom Up and Down | 175bar |
| Function Main Relief Pressure, used for Lower & Mid Boom Up and Down; Main Boom Up and Down | 210 bar |
| Turntable Swing Pressure Setting | 70 bar |
| Main Boom Telescopic Extend and Retract Pressure Setting | 180 bar |
| Jib Up and Down Pressure Setting Platform Rotate R&L Pressure Setting | 124 bar |
| Platform Level Up Pressure Setting | 190 bar |
| Platform Level Down Pressure Setting | 124 bar |
| Steering Pressure Setting | 124 bar |
| Hydraulic Reservoir | |
| Maximum Capacity | 120L |
| Auxiliary Pump Unit | |
| Electric Motor | 12V/1.5 kW/2800rpm |
| Displacement per revolution | 2.3cc |

2.4 Kubota V2403-M Engine Specification

| | |
|---|--|
| Displacement | 2.434L |
| Number of Cylinder | 4 |
| Bore & Stroke | 87×102.4(mm) |
| Rated Power | 34.1kW(Gross)/2400(rpm) |
| Firing Order | 1-3-4-2 |
| Low Idle | 1150~1250(rpm) |
| High Idle | Less than 2645(rpm) |
| Governor | Centrifugal ball type all speed governor |
| Compression Ratio | 20.5 |
| Valve Clearance, cold | |
| Intake Resistance | ≅ 2.45(250) kPa(mmAq) |
| Exhaust Gas Volume | 7.64(m ³ /min) |
| Lubrication System | |
| Oil Pressure Switch | 0.5kgf/cm ² |
| Lub Oil Capacity | 9.5L |
| Oil Viscosity Requirements | Better than API CD class.10W-30 |
| Use Oil Meeting API Classification SF(labeled SF/CC or SF/CD) for Improved Wear protection. | |
| Starter Motor | 12V-2.0kW |
| Battery | |
| Type | 12V80AH equivalent |
| Quality | 1 |
| Fuel Pump | Mechanical |
| Engine Coolant | LLC50%:50% |
| Cooling System | Pressurized Radiator, forced Circulation with Water Pump |
| Alternator | |
| Output | 12V-40A |
| Fan belt Deflection | 10mm |

2.5 Perkins 404D-22 Engine Specification

| | |
|---|--|
| Displacement | 2.216 Liters |
| Number of Cylinder | 4 |
| Bore & Stoke | 84*100mm |
| Rated Power | 35.7kW±5%/2600rpm |
| Firing Order | 1-3-4-2 |
| Low Idle | 1200rpm |
| High Idle | 2600rpm |
| Governor | Centrifugal ball mechanical |
| Compression Ratio | 23.3:1 |
| Valve Clearance, cold | |
| Intake Resistance | Cleanly inhaler: 3kPa Smudgy inhaler: 6.4kPa |
| Exhaust Gas Volume | 10.2kPa |
| Lubrication System | |
| Oil Pressure, hot (at 2000rpm) | 0.3kg/cm ² |
| Oil Capacity (Including Filter) | 8.9 to 10.6 liters |
| Oil Viscosity Requirement | Please refer the Engine Operator Manual for detail information. |
| Unit ships with 15-W40 oil, Extreme operating temperatures may require the use of alternative engine oils. Please refer the Engine Operator Manual for detail information. | |
| Battery | |
| Type | 12V/80AH |
| Quality | 1 |
| Fuel Requirement | |
| Please refer to the engine Operator's Manual on your machine for Detail information. | |
| Engine Coolant | |
| Capacity | 3.6 L |
| Fuel Pump | Electric |
| Alternator | |

| | |
|---------------------|-----------|
| Output | 65A@12VDC |
| Fan belt Deflection | 10 mm |

2.6 Bolt Torque Specification

| Thread Size | Class 8.8 Metric Bolts and Nuts (Nm) | Class 10.9 Metric Bolts and Nuts (Nm) | Class 12.9 Metric Bolts and Nuts (Nm) |
|-------------|--------------------------------------|---------------------------------------|---------------------------------------|
| M4 | 3 | 4.4 | 5.1 |
| M5 | 5.9 | 8.7 | 10 |
| M6 | 10 | 16 | 18 |
| M8 | 25 | 36 | 43 |
| M8x1 | 27 | 39 | 46 |
| M10 | 49 | 72 | 84 |
| M10x1 | 52 | 76 | 90 |
| M12x1.25 | 93 | 135 | 160 |
| M12x1.5 | 89 | 130 | 155 |
| M12 | 86 | 126 | 145 |
| M14x1.5 | 145 | 215 | 255 |
| M14 | 135 | 200 | 236 |
| M16x1.5 | 226 | 330 | 390 |
| M16 | 210 | 310 | 365 |
| M18x1.5 | 340 | 485 | 570 |
| M18 | 300 | 430 | 600 |
| M20x1.5 | 475 | 680 | 790 |
| M20 | 425 | 610 | 710 |
| M22x1.5 | 630 | 900 | 1050 |
| M22 | 580 | 820 | 960 |
| M24x2 | 800 | 1150 | 1350 |
| M24 | 730 | 1050 | 1220 |
| M27x2 | 1150 | 1650 | 1950 |
| M27 | 1100 | 1550 | 1800 |
| M30x2 | 1650 | 2350 | 2750 |
| M30 | 1450 | 2100 | 2450 |

User responsibility, Machine Preparation and Inspection

Section 3

3.1 Personnel Training

The aerial platform is a personnel handling device; so it is necessary that it be operated and maintained only by trained personnel.

WARNING

PERSONS UNDER THE INFLUENCE OF DRUGS OR ALCOHOL OR WHO ARE SUBJECT TO SEIZURES, DIZZINESS OR LOSS OF PHYSICAL CONTROL MUST NOT OPERATE THIS MACHINE.

3.1.1 Operator Training

Operator training must cover:

- Use and limitations of the controls in the platform and at the ground, emergency controls and safety systems.
- Control labels, instructions, and warnings on the machine.
- Rules of the employer and government regulations.
- Use of approved fall protection device.
- Enough knowledge of the mechanical operation of the machine to recognize a malfunction or potential malfunction.
- The safest means to operate the machine where overhead obstructions, other moving equipment, and obstacles, depressions, holes, drop offs.
- Means to avoid the hazards of unprotected electrical conductors.
- Specific job requirements or machine application.

3.1.2 Training Supervision

Training must be done under the supervision of a qualified person in an open area free of obstructions until the trainee has developed the ability to safely control and operate the machine.

3.1.3 Operator Responsibility

The operator must be instructed that he/she has the responsibility and authority to shut down the machine in case of a malfunction or other unsafe condition of either the machine or the job site.

3.2 Preparation, Inspection and Maintenance

3.2.1 General

This section provides the necessary information needed by those personnel that are responsible to place the machine in operation readiness, and lists checks that are performed prior to use of the machine. It is important that the information contained in this section be read and understood before any attempt is made to operate the machine. Ensure that all the necessary inspections have been completed successfully before placing the machine into service. These procedures will aid in obtaining maximum service life and safe operation.

The following table covers the periodic machine inspections and maintenance recommended by Dingli Machinery Co.,Ltd. Consult local regulations for further requirements for aerial work platforms. The frequency of inspections and maintenance must be increased as necessary when the machine is used in a harsh or hostile environment, if the machine is used with increased frequency, or if the machine is used in a severe manner.

Table 3-1. Inspection and Maintenance Table

| Type | Frequency | Primary Responsibility | Reference |
|---------------------------|---|------------------------|--|
| Pre-Start Inspection | Before using each day; or whenever there's an Operator change. | User or Operator | Operator and Safety Manual |
| Pre-Delivery Inspection | Before each sale, lease, or rental delivery. | Owner, Dealer, or User | Operation and Maintenance Manual and applicable Dingli Inspection Form |
| Frequent Inspection | In service for 3 months or 150 hours, whichever comes first; or Out of service for a period of more than 3 months; or Purchased used. | Owner, Dealer, or User | Operation and Maintenance Manual and applicable Dingli Inspection Form |
| Annual Machine Inspection | Annually, no later than 13 months from the date of prior inspection. | Owner, Dealer, or User | Operation and Maintenance Manual and applicable Dingli Inspection Form |
| Preventative Maintenance | At intervals as specified in the Operation & Maintenance Manual | Owner, Dealer, or User | Operation and Maintenance Manual and applicable Dingli Inspection Form |

3.2.2 Preparation for Use

Before a new machine is put into operation it must be carefully inspected for any evidence of damage resulting from shipment and inspected periodically thereafter, as outlined in Delivery and Frequent Inspection (see section 3.2.3). During initial start-up and run, the unit should be thoroughly checked for hydraulic leaks. A check of all components should be made to assure their security.

All preparation necessary to place the machine in operation readiness status is the responsibility of management personnel. Preparation requires good common sense, (i.e. telescope works smoothly and brakes operate properly) coupled with a series of visual inspections. The mandatory requirements are given in the Daily Walk around Inspection (see section 3.2-4).

It should be assured that the items appearing in the Delivery and Frequent Inspection and Functional Check are complied with prior to putting the machine into service.

3.2.3 Delivery and Frequent Inspection

NOTICE

AN ANNUAL INSPECTION SHALL BE PERFORMED ON THE AERIAL PLATFORM NO LATER THAN THIRTEEN (13) MONTHS FORM THE DATE OF THE PRIOR ANNUAL INSPECTION. THE INSPECTION SHALL BE PERFORMED BY PERSON(S) QUALIFIED AS A MECHANIC ON THE SPECIFIC MAKE AND MODEL OF THE AERIAL PLATFORM.

The following checklist provides a systematic inspection to assist in detecting defective, damaged, or improperly installed parts. The checklist denotes the items to be inspected and conditions to examine. Frequent inspection shall be performed every 3 months or 150 hours whichever comes first or more often when required by environment, severity, and frequency of usage.

This inspection checklist is also applicable and must be followed for all machines that have been in storage or for all machines that will be exposed to harsh or changing climates. These checks are also to be performed after maintenance has been performed on the machine.

Chassis

- 1) Check front tires and wheel assemblies for loose or worn spindles, components and hardware for security, tires for wear and damage.
- 2) Check steering assembly for loose or bent tie rod, cylinder and hydraulic lines for leaks and security, and hardware for proper installation.
- 3) If equipped with 4WD, check drive hubs, hydraulic motors, brakes and hydraulic lines for damage and leaks.
- 4) Check rear tires and wheel assemblies for security, tires for wear and damage.
- 5) Check drive hubs, hydraulic motors, brakes and hydraulic lines for damage and leaks.
- 6) Check oil level in drive hub by removing pipe plug on side and feeling for oil level. (Contact Service Personnel for assistance if needed).

NOTICE

TORQUE HUBS SHOULD BE ONE-HALF FULL OF LUBRICANT.

- 7) Check oscillating axle (if equipped) for loose, missing and worn parts, pivot pin and lockout cylinder pins for security, lockout cylinders and hydraulic hoses for damage and leaks.

Turntable

- 1) Check turntable for damage, loose or missing parts, and security. Check swing drive and brake for damage, loose or missing parts, hydraulic lines and component housings for evidence of leakage; worm gear for proper mesh with swing gear.
- 2) Check swing bearing for damage, wear, lubrication and loose or missing bearing bolts.
- 3) Check solenoid valves and hydraulic lines for damage, leakage, security and electrical connections for tightness and evidence of corrosion.
- 4) Check ground controls for damage, loose or missing parts, security and electric connections for evidence of corrosion and tightness and wiring for insulation damage. Assure that all switches function properly.
- 5) Check battery for damage, loose or missing vent caps, electrical connections for tightness, and evidence of corrosion, hold-down brackets for tightness, and electrolyte for proper water level. Add only clean distilled water to battery.
- 6) Check engine tray pivot assembly for damage, loose or missing parts, and security.
- 7) Check engine and accessories for damage, loose or missing parts, leakage and security. Check throttle solenoid and linkage for damage, electrical connections for tightness, and evidence of corrosion and wiring for insulation damage.
- 8) Check fuel lines for damage, leakage and security.
- 9) Check all access doors for damage, proper operation of latches, props and security.
- 10) Check fuel tank for damage, leakage and filler cap for security.
- 11) Check hydraulic reservoir and hydraulic lines for damage, leakage and security.

NOTICE

DINGLI CO.,LTD. RECOMMENDS REPLACING THE HYDRAULIC FILTER ELEMENT AFTER THE FIRST 50 HOURS OF OPERATION AND THEN EVERY 300 HOURS THEREAFTER, UNLESS SYSTEM INDICATOR REQUIRE EARLIER REPLACEMENT.

- 12) Check all pin and shaft retaining hardware for security and wear.
- 13) Check all electrical cables for defects, damage, loose or corroded connections.

Boom

- 1) Check Lower Boom and leveling link for damage, missing parts and security.
- 2) Check all pin and shaft retaining hardware for security and wear.
- 3) Check hydraulic lines and electrical cable for damage, missing parts and security.
- 4) Check limits switch connections and plunger for corrosion and security.
- 5) Check Lower Upright, cross pins、 lower hydraulic cylinder and hydraulic lines for damage, wear, lubrication, leakage and security.

- 6) Check boom pivot bushings for wear.
- 7) Check Upper Upright, cross pins ,upper lift cylinder and hydraulic lines for damage, wear, lubrication, leakage and security.
- 8) Check Upper Boom for damage, missing parts and security.
- 9) Check Upper Boom wear pads for damage, missing parts and security.
- 10) Check Upper Boom telescope cylinder, cross pins and hydraulic lines for damage, wear, lubrication, leakage and security.
- 11) Check Platform Leveling Cylinder, cross pins and hydraulic lines for damage, wear, lubrication, leakage and security.
- 12) Check jib articulating cylinder, cross pins and hydraulic lines for damage, wear, lubrication, leakage and security.
- 13) Check solenoid valve for transition platform swinging and jib lifting, connection-peg and cable for damage, wear and security.

Platform

- 1) Check platform and control console for damage, loose or missing parts, and security.
- 2) Check control switches and levers for damage, loose or missing parts and security. Assure that levers function properly.
- 3) Check control switches, levers and electrical connections for tightness and evidence of corrosion, and wiring for defects and chafing damage. Assure that switches function properly.
- 4) Check access gate hinges, stop, and latch for proper operation, damage and security.
- 5) Check platform rotator mechanism for proper operation, damage, security. Check hydraulic lines for leakage, damage and security.

NOTICE

***CHECK ALL DANGER, WARNING, CAUTION AND INSTRUCTION
PLACARDS FOR LEGIBILITY AND SECURITY ON THE ENTIRE MACHINE.
(REFER TO SECTION 4.4 PLACARDS AND DECALS)***

Torque Requirements

The Reference Torque Value for Metric Thread Table (Figure 2-6.) consists of standard Metric bolts and Nuts torque values based on bolt diameter and grade, also specifying dry and wet torque values in accordance with recommended shop practices. This chart is provided as an aid to the operator in the event he/she notices a condition that requires prompt attention during the walk-around inspection or during operation, until the proper service personnel can be notified. The Service and Maintenance manual provides specific torque values and periodic maintenance procedures with a listing of individual components. Utilizing this Torque Value Table in conjunction with the preventive maintenance section will enhance safety, reliability, and performance of the machine.

3.2.4 Daily Walk-around Inspection

It is the operator's responsibility to inspect the machine before the start of each workday. It is recommended that each operator inspect the machine before operation, even if the machine has already been put into service under another operator. This Daily Walk-Around Inspection is the preferred method of inspection. These checks are also to be performed after maintenance has been performed on the machine.

In addition to the Daily Walk-Around Inspection, be sure to include the following as part of the daily inspection:

1) Overall cleanliness.

Check all standing surfaces for oil, fuel and hydraulic oil spillage and foreign objects. Ensure overall cleanliness.

2) Placards.

Keep all information and operating placards clean and unobstructed. Cover when spray painting or shot blasting to protect legibility.

3) Operator's and Safety Manual.

Ensure a copy of this manual and other Safety Manual, are enclosed in the manual storage box.

4) Machine Log.

Ensure a machine operating record or log is kept, check to see that it is current and that no entries have been left unlearned, leaving machine in an unsafe condition for operation.

5) Start each day with a full fuel tank.

⚠ WARNING

TO AVOID INJURY, DO NOT OPERATE A MACHINE UNTIL ALL MALFUNCTIONS HAVE BEEN CORRECTED. USE OF A MALFUNCTIONING MACHINE IS A SAFETY VIOLATION. TO AVOID POSSIBLE INJURY, BE SURE MACHINE POWER IS "OFF" DURING WALK-AROUND INSPECTION.

NOTICE

CHECK BOOM LIMIT SWITCHES ON UPRIGHT FOR PROPER OPERATION AND SECURITY, BOTH VISUALLY AND MANUALLY. THE LOWER SWITCH CUTS OUT DRIVE SPEED WHEN THE LOWER BOOM IS ABOVE HORIZONTAL. THE UPPER SWITCH CUTS OUT DRIVE SPEED WHEN THE UPPER BOOM IS ABOVE HORIZONTAL. ONLY CREEP DRIVE SPEED WILL CONTINUE TO FUNCTION.

6) Check platform footswitch for proper operation.

Switch must be released to start engine and depressed to operate machine.

7) Check that drive brakes hold when machine is driven up a grade not greater than specified on the serial number placard and stopped.

NOTICE

ON NEW MACHINES, THOSE RECENTLY OVERHAULED, OR AFTER CHANGING HYDRAULIC OIL, OPERATE ALL SYSTEMS A MINIMUM OF TWO COMPLETE CYCLES AND RECHECK OIL LEVEL IN RESERVOIR.

8) Assure that all items requiring lubrication are serviced.

Refer to Figure 3-1, Lubrication Diagram for specific requirements.




Figure 3-1 Daily Walk-around Inspection Position

Walk-Around Inspection Checklist

- 1) **Platform Assembly** – No loose or missing parts, no visible damage. Lock bolts in place. Footswitch in good working order not modified disabled or blocked.
- 2) **Platform Control Console** – Switches and levers return to neutral and are properly secured, no loose or missing parts, no visible damage, decals/placards secure and legible, control marking legible.
- 3) **Jib Articulating Cylinder** – No visible damage; pivot pins secure; hydraulic hoses undamaged, not leaking.
- 4) **Slave Cylinder** – No visible damage; pivot pins secure; hydraulic hoses undamaged, not leaking
- 5) **Boom Sections/Uprights/Lift Cylinders and Master Cylinder** – No visible damage; pivot pins secure; hydraulic hoses undamaged, not leaking. Uprights in vertical position.
- 6) **Wheel/Tire Assembly, Right Rear** – Properly secured, no loose or missing lug nuts, no visible damage.
- 7) **Drive Motor, Brake, and Hub** – No visible damage; no evidence of leakage.
- 8) **Control Valve** – No loose or missing parts; evidence of leakage; unsupported wires or hoses; damaged or broken wires.
- 9) **Hood, Right Side** – Properly secured; no loose or missing parts
- 10) **Ground Controls** – Switches operable, no visible damage, decals secure and legible.
- 11) **Fuel Supply** – Filler cap secure, no visible damage to the tank or evidence of leaks.
- 12) **Tie Rod Ends and Steering Spindles** – No loose or missing parts; no visible damage.
- 13) **Drive Motor, Brake, and Hub** – No visible damage; no evidence of leakage.
- 14) **Oscillating Axle** – No loose or missing hardware; no visible damage.
- 15) **Wheel/Tire Assembly, Right Front** – Properly secured, no loose or missing lug nuts, no visible damage.
- 16) **Wheel/Tire Assembly, Left Front** – Properly secured, no loose or missing lug nuts, no visible damage.
- 17) **Drive Motor, Brake, and Hub** – No visible damage; no evidence of leakage.
- 18) **Tie Rod Ends and Steering Spindles** – No loose or missing parts; no visible damage.
Steer Cylinder – Properly secured; no visible damage or signs of leakage; evidence of proper lubrication.
- 19) **Hydraulic Oil Supply** – Recommended oil level sight gauge. (Check level with cold oil, systems shut down, machine in stowed position) Cap in place and secure.
Hydraulic Filter – Housing secure no visible damage; no evidence of leakage,
- 20) **Horizontal Limit Switches** – Switches operable; no visible damage.

- 21) **Engine Air Filter** – No loose or missing parts; no visible damage; element clean.
Engine Oil Supply – Full mark on dipstick; filler cap secure.
Muffler and Exhaust System – Properly secured no evidence of leakage. Check the coolant level.
- 22) **Hood, Right Side** – Properly secured; no loose or missing parts.
- 23) **Turntable Bearing** – No loose or missing hardware; no visible; evidence of proper lubrication; no evidence of loose bolts or looseness between bearing or structure.
Swing Motor and Worm Gear – No loose or missing hardware; no visible damage; evidence of proper lubrication.
- 24) **Hydraulic Pump** – No loose or missing parts, no evidence
- 25) **Battery** – Proper electrolyte levels; cables tight, no visible damage or corrosion.
- 26) **Drive Motor, Brake, and Hub** – No visible damage; no evidence of leakage.
- 27) **Wheel/Tire Assembly, Left Rear** – Properly secured, no loose or missing lug nuts, no visible damage.
- 28) **Rotator Cylinders** – No visible damage; cylinder bolts secure; hydraulic hoses undamaged and not leaking.
- 29) **Platform Gate** – Latch, stop, and hinges in working condition and properly secured; no loose or missing parts.

3.2.5 Daily Function Check

A functional check of all systems must be performed, once the walk-around inspection is complete, in an area free of overhead and ground level obstructions. First, using the ground controls, check all functions controlled by the ground controls. Next, using the platform controls, check all functions controlled by the platform controls.

WARNING

TO AVOID SERIOUS INJURY, DO NOT OPERATE MACHINE IF ANY CONTROL LEVERS OR TOGGLE SWITCHES CONTROLLING PLATFORM MOVEMENTS DO NOT RETURN TO THE OFF OR NEUTRAL POSITION WHEN RELEASED.

TO AVOID A COLLISION AND INJURY IF PLATFORM DOES NOT STOP WHEN A CONTROL SWITCH OR LEVER IS RELEASED, REMOVE FOOT FROM FOOTSWITCH OR USE EMERGENCY STOP TO STOP THE MACHINE.

IF THE MACHINE DOES NOT OPERATE PROPERLY, TURN OFF THE MACHINE IMMEDIATELY! REPORT THE PROBLEM TO THE PROPER MAINTENANCE PERSONNEL. DO NOT OPERATE THE MACHINE UNTIL IT IS DECLARED SAFE FOR OPERATION.

NOTICE

WHEN THE BOOM IS RAISED ABOVE HORIZONTAL, HIGH DRIVE SPEED IS CUT OUT.

- 1) Check boom horizontal limit switches to see that they are operable and not damaged. Raise and lower Boom. Check for smooth operation. Check Boom Upright tilting for proper synchronization. If the upright is tilted or the boom will not fully lower, refer to the Boom Operation in Section 5.8.

NOTICE

PERFORM CHECKS FROM GROUND CONTROLS FIRST, THEN FROM PLATFORM CONTROLS.

- 2) Raise, extend, retract and lower Upper Boom. Check for smooth operation.
- 3) Telescope boom IN and OUT several cycles at various degrees of elevation lengths. Check for smooth telescope operation.
- 4) Swing turntable to LEFT and RIGHT a minimum of 45 degrees. Check for smooth motion.
- 5) With the aid of an assistant to monitor the CHASSIS OUT OF LEVEL indicator light on the platform console, manually activate the indicator light by compressing one of the three tilt indicator mounting springs. If the light does not illuminate, shut down machine and contact a qualified service technician before continuing operation.
- 6) Check that platform self-leveling system functions properly during raising and lowering of boom.
- 7) Check rotator for smooth operation and assure platform will rotate 75 degrees in both directions from centerline of boom.
- 8) Drive forward and reverse; check for proper operation.
- 9) Steer left and right; checks for proper operation.
- 10) Footswitch.

⚠ WARNING

FOOTSWITCH MUST BE ADJUSTED SO THAT FUNCTIONS WILL OPERATE WHEN PEDAL IS APPROXIMATELY AT ITS CENTER OF TRAVEL. IF SWITCH OPERATES WITHIN LAST 1/4" OF TRAVEL, TOP OR BOTTOM, IT SHOULD BE ADJUSTED.

- A. Activate hydraulic system, by depressing footswitch. Operate Telescope and hold control. Remove foot from footswitch, motion should stop. If it does not, shut down machine and contact a certified service technician.
- B. With footswitch depressed, operate Lift and hold control. Remove foot from footswitch, motion

should stop. If it does not, shut down machine and contact a certified service technician.

- C. With engine power shut down, depress the footswitch. Attempt to start engine. Engine should not attempt to start when footswitch is depressed. If starter engages or engine turns over, shut down machine and contact a certified service technician.

11) Auxiliary Power.

Operate each function control switch (e.g. Tele, Lift, and Swing) to assure that they function in both directions using auxiliary power instead of engine power.

12) Ground Controls.

Place Ground/Platform Select switch to Ground.

Start engine. Platform controls should not operate.

3.3 Oscillating Axle Lockout Test (If Equipped)

NOTICE

LOCKOUT SYSTEM TEST MUST BE PERFORMED QUARTERLY, ANY TIME A SYSTEM COMPONENT IS REPLACED, OR WHEN IMPROPER SYSTEM OPERATION IS SUSPECTED.

ENSURE BOOM IS FULLY RETRACTED, LOWERED AND CENTERED BETWEEN DRIVE WHEELS PRIOR TO BEGINNING LOCKOUT CYLINDER TEST.

- 1) Place 20cm high block with ascension ramp in front of left front wheel.
- 2) From platform control station, start engine.
- 3) Place the Drive control lever to the forward position and carefully drive machine up ascension ramp until left front wheel is on top of block.
- 4) Carefully activate Swing control lever and position boom over right side of machine.
- 5) With boom over right side of machine, place Drive control lever to Reverse and drive machine off of block and ramp.
- 6) Have an assistant check to see that left front or right rear wheel remains elevated in position off of ground.
- 7) Carefully activate Swing control lever and return boom to stowed position (centered between drive wheels). When boom reaches center, stowed position, lockout cylinders should release and allow wheel to rest on ground, it may be necessary to activate Drive to release cylinders.
- 8) Place the 8 inches (20 cm) high block with ascension ramp in front of right front wheel.
- 9) Place Drive control lever to Forward and carefully drive machine up ascension ramp until right front wheel is on top of block.
- 10) With boom over left side of machine, place Drive control lever to Reverse and drive machine off of block and ramp.

- 11) Have an assistant check to see that right front or left rear wheel remains elevated in position off of ground.
- 12) Carefully activate Swing control lever and return boom to stowed position (centered between drive wheels). When boom reaches center, stowed position, lockout cylinders should release and allow wheel to rest on ground, it may be necessary activate Drive to release cylinders.
- 13) If lockout cylinders do not function properly, have qualified personnel correct the malfunction prior to any further operation.

Machine Controls and Indicators

Section 4

4.1 General

NOTICE

THE MANUFACTURER HAS NO DIRECT CONTROL OVER MACHINE APPLICATION AND OPERATION. THE USER AND OPERATOR ARE RESPONSIBLE FOR CONFORMING WITH GOOD SAFETY PRACTICES.

This section provides the necessary information needed to understand control functions.

4.2 Controls and Indicators

4.2.1 Ground Control Station

NOTE: The Enabling Switch must be held down in order to operate Telescope, Swing, Tower Lift, Main Lift, Jib Lift, Platform Level Override, and Platform Rotate functions.

⚠ WARNING

DO NOT OPERATE FROM GROUND CONTROL STATION WITH PERSONNEL IN THE PLATFORM EXCEPT IN AN EMERGENCY.

PERFORM AS MANY PRE-OPERATIONAL CHECK AND INSPECTIONS FROM GROUND CONTROLS AS POSSIBLE.


















Figure 4-1 Ground Console Panel

Table 4-1 the Explanation for the Ground Console Panel

| Item | Name | Description |
|------|--|--|
| 1 | <p>The Multifunction Gauge</p>  | <p>The Multifunction Gauge, is used to Display the</p> <ul style="list-style-type: none"> ● Fuel level ● Working Hours Meter ● the Alarm Light for the Engine High Coolant Temperature Arrived the 105°C ● the Alarm Light for the Engine Low Oil Pressure |
| 2 | <p>The Engine Speed Control Switch</p>  | <p>A Three Position Toggle Switch, which is used to set the engine speed and choose the Auxiliary Power to operate the machine in emergency situation while the engine does work. it would return Back to Original Position Automatically once be released.</p> <ul style="list-style-type: none"> ● The engine speed is set at Low speed default after the engine is started. ● Push the Toggle Switch to Rabbit direction and hold on, the engine would be turning in highest speed, no matter a function action is chosen or not; once released, it return back to turn in low speed. ● Push the Toggle Switch to battery direction and hold on, the emergency power would be chosen. <div style="text-align: center;">  </div> <p><i>Platform console: the emergency power only is function for platform swinging, jib lifting up and down, lower boom and upper boom lifting down, upper boom retracting, turntable rotating and leveling up and down;</i></p> <p><i>Ground console: the emergency power only is function for,jib lifting down, lower boom and upper boom lifting down, upper boom retracting, turntable rotating and leveling up and down.</i></p> <p><i>Check auxiliary power daily.</i></p> |

| Item | Name | Description |
|------|--|---|
| 3 | <p>Enabling Switch</p>  | <p>A two position toggle switch. Normally it is kept in neutral position when released.</p> <ul style="list-style-type: none"> ● Before operating any function, the switch must be depressed. Not being depressed would invalidate the operation of any function. |
| 3 | <p>The Ground and Platform Console Selecting Switch</p>  | <p>A three position toggle switch is used to supplies power to the platform console or platform console when positioned to Platform.</p> <ul style="list-style-type: none"> ● Normally, it is in Neutral, the Power is cut off ● Turn the Key Switch Counter-clockwise to the Blue Square Position, the machine would be controlled by the Platform Console ● Turn the Key Switch Clockwise to the Red Circle Position, the machine would be controlled by the Ground Console. <p style="text-align: center;">NOTICE</p> <p><i>When machine is shut down the Platform/Ground Select switch and Emergency Stop must be positioned to OFF.</i></p> <p><i>With PLATFORM/GROUND SELECT switch in the center position, power is shut off to controls at both operating Console.</i></p> |
| 4 | <p>Engine Starting Switch</p>  | <p>A three position Toggle Switch, Normally it is kept in neutral position when released. It is used to start the engine or power the glow plug to assist to start the engine in cold weather.</p> <ul style="list-style-type: none"> ● As to start engine, to push the toggle switch Forward to the Key Icon, until the engine starts running, it would return Back to Original Position Automatically once be released. ● In cold weather, when the engine is difficult to start, Pulling the toggle switch lever down to Glow Plug Icon and keeping about 7 second, the glow plug would be energized, then push the goggle switch up to Key Icon to start the engine. <p style="text-align: center;">NOTICE</p> <p><i>If failed to start the engine, more than 25 second must be waited for before next starting.</i></p> |

| Item | Name | Description |
|------|--|--|
| 5 | <p>The Turntable Swing Control Switch</p>  | <p>A three position Toggle Switch allows the operator to swing the turntable to left or right according the indication direction. it would return Back to Original Position Automatically once be released.</p> |
| 6 | <p>Emergency Button</p>  | <p>A two-position red mushroom shaped switch furnishes power to Ground Select switch, it is used to shut down the engine and turn off the system power in emergency situation.</p> <ul style="list-style-type: none"> ● Push Down to turn (OFF) the switch, so the power is shut off. ● Before starting engine, the emergency button must be released, if not, the engine can not be started. Turning the mushroom clockwise to turn ON the switch, so to provide the power to the system. |
| 7 | <p>The Control Switch for Lower and Mid Boom Up & Down</p>  | <p>A Three Position Toggle Switch. Push the toggle lever Up according to UP Arrow direction, the Lower and the Mid Boom would be raised simultaneously, until the Boom Up to the Up limited position. And Push the toggle lever to the opposite direction, the Lower and Mid Boom would be got Down until the Boom to the Lowest Position. Once the toggle lever is released, it would return to the Original position automatically.</p> |
| 8 | <p>The Main Boom Up and Down Controller</p>  | <p>A Three Position Toggle Switch. Push the toggle lever Up according to UP Arrow direction, the Main Boom would be raised, until the Boom Up to the Up limited position. And Push the toggle lever to the opposite direction, the Main Boom would be got Down until the Boom to the Lowest Position. Once the toggle lever is released, it would return to the Original position automatically.</p> |

| Item | Name | Description |
|------|---|--|
| 9 | <p>The Main Boom Telescopic Controller</p>  | <p>A Three Position Toggle Switch. Push the toggle lever LEFT according to LEFT Arrow direction, the Main Boom would be Extended, until the Boom extend to the extending limited position. And Push the toggle lever to the opposite direction, the Main Boom would be extended until the Boom to the retracting Position. Once the toggle lever is released, it would return to the Original position automatically.</p> |
| 10 | <p>The Jib Boom Up & Down Controller</p>  | <p>A Three Position Toggle Switch. Push the toggle lever Up according to UP Arrow direction, the Jib Boom would be raised, until the Boom Up to the Up limited position. And Push the toggle lever to the opposite direction, the Jib Boom would be got Down until the Boom to the Lowest Position. Once the toggle lever is released, it would return to the Original position automatically.</p> |
| 11 | <p>The Platform Rotate Controller</p>  | <p>A three position Toggle Switch allows the operator to swing the platform to left or right according the indication direction. it would return Back to Original Position Automatically once be released.</p> <div style="text-align: center;"> <p>NOTICE</p> <p><i>Range of platform swinging: $\pm 90^\circ$</i></p> </div> |
| 12 | <p>The Platform Leveling Controller</p>  | <p>A three position switch allows the operator to adjust the automatic self leveling system. This switch is used to adjust the platform level in situations such as ascending/descending a grad.</p> <div style="text-align: center;"> <p>WARNING</p> <p><i>ONLY USE THE PLATFORM LEVELING OVERRIDE FUNCTION FOR SLIGHT LEVELING OF THE PLATFORM. INCORRECT USE COULD CAUSE THE LOAD/OCCUPANTS TO SHIFT OR FALL. FAILURE TO DO SO COULD RESULT IN DEATH OR SERIOUS INJURY.</i></p> </div> |

4.2.2 Platform Control Station





















Figure 4-2 Platform Console Panel



Table 4-2 The Explanations for the Platform Console

| Item | Name | Description |
|------|---|---|
| 1 | <p>The Auxiliary Power Control Switch</p>  | <p>The Auxiliary Power control switch energizes the electrically operated hydraulic pump. (Switch must be held ON for duration of auxiliary pump use.)</p> <p>Platform console: the emergency power only is function for platform swinging, jib lifting up and down, lower boom and upper boom lifting down, upper boom retracting, turntable rotating and leveling up and down;</p> <p>Ground console: the emergency power only is function for, jib lifting down, lower boom and upper boom lifting down, upper boom retracting, turntable rotating and leveling up and down.</p> |
| 2 | <p>The Glow Plug Control Switch</p>  | <p>A two position Toggle Switch. It is used for assisting method to start the engine when the temperature is lower. Push Forward and Hold it about 7 Second, then release the toggle lever to Push the Start Toggle Switch to Start the engine.</p> |
| 3 | <p>The Engine Start Switch</p>  | <p>A two position Toggle Switch, Push Up Forward until the engine starts, it would return Back to Original Position Automatically once be released.</p> <div style="text-align: center; background-color: #0070C0; color: white; padding: 5px; margin: 10px 0;">NOTICE</div> <p><i>When start the engine,push forward and hold it less than 20 second.If failed to start the engine, more than 25 second must be waited for before next starting.</i></p> |
| 4 | <p>The Driving Enable Override Switch</p>  | <p>Not used</p> |

| Item | Name | Description |
|------|--|---|
| 5 | Emergency Button  | A two-position red mushroom shaped switch furnishes power to Ground Select switch, it is used to shut down the engine and turn off the system power in emergency situation. <ul style="list-style-type: none"> ● Push Down to turn (OFF) the switch, so the power is shut off. ● Before starting engine, the emergency button must be released, if not, the engine can not be started. Turning the mushroom clockwise to turn ON the switch, so to provide the power to the system. |
| 6 | The Control EUM Unit and Panel  Refer to Display Panel for detail information | |
| 7 | The Horn Button  | A Two Position Toggle Switch. If pressed, this switch supplies power to the horn. It would return Back to Original Position Automatically once be released. |
| 8 | The Driving Mode Choosing Switch  | A Two Position Toggle Switch, which is used to Set the Driving Mode. <ul style="list-style-type: none"> ● Turn the Toggle Switch to Right position, the machine can provide maximum drive speed by shifting the drive motors to minimum displacement and giving high engine when drive controller is moved. ● Turn the Toggle Switch to Left position, the machine can provide maximum torque for rough terrain and climbing grades by shifting the wheel motors to maximum displacement and giving high engine speed;. |

| Item | Name | Description |
|------|---|---|
| 8 | <p>The Driving Mode Choosing Switch</p>  | <div style="background-color: yellow; text-align: center; padding: 5px;">⚠ CAUTION</div> <p><i>If the machine is not stowed, it would be only driven a low speed, less than 1.1km/h. If not, shut down machine and contact a qualified service technician before continuing operation. Failure to do so could result in death or serious injury.</i></p> |
| 9 | <p>The Engine Speed Control Switch</p>  | <p>A Two-Position Toggle Switch, spring return, which is used to set the engine speed.</p> <ul style="list-style-type: none"> ● Push up Toggle Switch and release it, the switch return back automatically. RPM appear in the display, the speed is shifted maximum. ● Push up Toggle Switch and release it again, the switch return back automatically. RPM disappear from the display, the speed is shifted minimum. ● Push up Toggle Switch and release it third time, the switch return back automatically. RPM appear in the display, the speed is shifted maximum again. |
| 10 | <p>AC Generator</p>  | <p>Not used</p> |
| 11 | <p>The Main Boom Controller</p>  | <p>The dual axis joystick is provided for main lift and swing.</p> <ul style="list-style-type: none"> ● Push down the button in top of the joystick and hold on ,then Push forward and hold on to raise the main boom (Upper boom) up, pull backward to lower the main boom (Upper boom). ● Move right to swing the turntable to right; move left to swing the turntable to left. <div style="background-color: blue; text-align: center; padding: 5px;">NOTICE</div> <p><i>Main lift and swing functions may be selected at the same time. Maximum speed is reduced when both functions are selected.</i></p> |

| Item | Name | Description |
|------|--|---|
| 12 | <p>The Lower and Mid Boom Control Switch</p>  | <p>A Three Position Toggle Switch. Push the toggle lever Up according to UP Arrow direction, the Lower and the Mid Boom would be raised simultaneously, until the Boom Up to the Up limited position. And Push the toggle lever to the opposite direction, the Lower and Mid Boom would be get Down until the Boom to the Lowest Position. Once the toggle lever is released, it would return to the Original position.</p> |
| 13 | <p>The Main Boom Telescopic Control Switch</p>  | <p>A Three Position Toggle Switch. Push the toggle lever LEFT according to LEFT Arrow direction, the Main Boom would be Extended, until the Boom extend to the extending limited position. And Push the toggle lever to the opposite direction, the Main Boom would be extended until the Boom to the retracting Position. Once the toggle lever is released, it would return to the Original position automatically.</p> |
| 14 | <p>The Platform Leveling Control Switch</p>  | <p>A three position switch allows the operator to adjust the automatic self leveling system. This switch is used to adjust the platform level in situations such as ascending/descending a grade.</p> <div style="text-align: center;">  <p>WARNING</p> </div> <p><i>ONLY USE THE PLATFORM LEVELING OVERRIDE FUNCTION FOR SLIGHT LEVELING OF THE PLATFORM. INCORRECT USE COULD CAUSE THE LOAD/OCCUPANTS TO SHIFT OR FALL. FAILURE TO DO SO COULD RESULT IN DEATH OR SERIOUS INJURY.</i></p> |
| 15 | <p>The Jib Boom Up & Down Control Switch</p>  | <p>A Three Position Toggle Switch. Push the toggle lever Up according to UP Arrow direction, the Jib Boom would be raised, until the Boom Up to the Up limited position. And Push the toggle lever to the opposite direction, the Jib Boom would be got Down until the Boom to the Lowest Position. Once the toggle lever is released, it would return to the Original position automatically.</p> |

| Item | Name | Description |
|------|---|---|
| 16 | <p>The Platform Rotate Control Switch</p>  | <p>A three position Toggle Switch allows the operator to swing the platform to left or right according the indication direction. it would return Back to Original Position Automatically once be released.</p> <p style="text-align: center;">NOTICE</p> <p style="text-align: center;"><i>Range of platform swinging: $\pm 90^\circ$</i></p> |
| 17 | <p>Drive/Steer Controller</p>  | <p>Drive/Steer</p> <p>The DRIVE joystick provides for driving either forward or backward. The controller is ramped to allow variable drive speed.</p> <p>Steering is controlled by a thumb operated switch on top of the joystick.</p> |

4.2.3 The Multi-Function Gauge











Figure 4-3 The Multi-Function Display Gauge

Table 4-3 The Explanations for the Multi-Function Gauge

| Item | Name & Figure | Description |
|------|---|--|
| 1 |  | Hydraulic Filter Warning indicator. It would be displayed once the filter is clogged. Change the filter element immediately. |
| 2 |  | Hydraulic oil high temperature Warning indicator. It would be displayed once the hydraulic oil temperature in the reservoir is higher more that 65°C. Then stop the machine immediately to cool the hydraulic oil, and make a troubleshooting. |
| 3 |  | Engine coolant high temperature Warning indicator. It would be displayed once the coolant temperature is higher more that 105°C. Stop the machine immediately to cool the coolant, and make a troubleshooting. |
| 4 |  | Engine Oil Presser Warning Indicator, it would be display once the engine oil pressure is too low. Stop the machine immediately to make a troubleshooting. |
| 5 |  | Battery Voltage low Warning indicator, it would be displayed once the battery voltage is too low. |
| 6 |  | System Error Warning indicator. It would be displayed once there is any trouble and error code would be glittering. |
| 7 |  | Low Charge Pressure Warning Indicator.(Option) It would be displayed and glitter once the charge pressure is less than 10bar. Stop the machine immediately to make a troubleshooting. Otherwise, failure to do so would cause damage to element of pump. |

4.2.4 The Control Unit Display Panel











Figure 4-4 the LED Control& Display Configuration







Function Key Description:

| Item | Name & Figure | Description |
|------|---|--|
| 1 |  | It is used to adjust the display panel contrast, press one time. |
| 2 |  | Go back to up class menu or display item. It is used to choose previews item when adjust the display menu. |
| 3 |  | Go down to the next display item. It is used to choose next item when adjust the display menu. |
| 4 |  | It is used to confirm you choosing when make adjusting for the control display. |

Indicator Light Description:

| Item | Name & Figure | Description |
|------|---|--|
| 1 |  | It is a red indicator light. It indicates that there are some warnings when it is illustrated. |
| 2 |  | It is a yellow indicator light. It indicates that the driving motor is in minor display and the machine can be drove in High speed when it is illustrated. |
| 3 |  | It is a green indicator light. It indicates that the footswitch is depressed when it is illustrated. |

The Icon in the Graphic Display Zone Description:

| Item | Name & Figure | Description |
|------|---|---|
| 1 |  | The ground control station indicator. It would be shown when the selected key switch is turned to the ground control station. |
| 2 |  | Indicate that the engine is turn off. |
| 3 |  | Indicate that the machine chassis is inline and the degree is more than 5 degree when the boom isn't lowered and retracted completely. So, some function operation can't be operated. |
| 4 | RPM | Indicate that the engine is in High speed working status. |
| 5 |  | Indicate that the emergency button is depressed down. |
| 6 |  | Indicate that the engine coolant temperature is more 105 degree. Stop the engine immaterially and make a troubleshooting. |
| 7 |  | Warning Indicator, it would be display once the engine oil pressure is too low. |

4.3 Tilt Alarm Warning

A Tilt Sensor is installed in the Turntable, which is used to detect if the chassis is horizontal. Once the Tilt Sensor detects that the chassis is inline and the inline degree is more than 5 degree, the sensor indicator light would turn to be red from green and an alarm will also sound as long as the lower and mid boom lifted, telescopic boom extended or main boom lifted. At the same time, red light on the platform control station will glitter and the corn indicating chassis inclining appear in the display. Then, the machine can't travel and the boom can't lift up and extend. The machine can be driven when the boom is lowered and retracted completely. Last, the machine should be driven to a safe and plat ground.



NOTICE


THE FOLLOWING INFORMATION IS ONLY APPLICABLE TO CE MACHINE: WHEN THE LEVEL OF THE CHASSIS EXCEED 5° AND ALARM4-1ED, ALL OPERATIONS OF THE MACHINE WOULD NOT BE OPERATED.

! DANGER

IT IS FORBIDDEN THAT RELEASE THE BOLT FIXING UP THE TILT SENSOR TO FREE FROM ALARM, OTHERWISE, IT WOULD CAUSE SERIOUS DAMAGE TO THE MACHINE OR DEATH TO PERSONS.

4.4 Footswitch/Enable Indicator

To operate any function, the footswitch must be depressed and then to choose the function selected within seven seconds. If a function is not selected within seven seconds, or if a seven second lapse between ending one function and beginning the next function, the enable function would go out and the footswitch must be released and depressed again to enable the controls.



NOTICE

FOR ENGINE STARTING, THE FOOTSWITCH MUST BE IN THE RELEASED (UP) POSITION.

! DANGER

TO AVOID SERIOUS INJURY, DO NOT REMOVE, MODIFY OR DISABLE THE FOOTSWITCH BY BLOCKING OR ANY OTHER MEANS.

4.5 Placards and Decals

Read and understand all placards and decals. Do not operate any machine on which DANGER, WARNING, CAUTION OR INSTRUCTION PLACARDS OR DECALS ARE MISSING OR ILLEGIBLE. Replace placards and decals if damaged, missing or illegible.

Decals are made of Pressure Sensitive Adhesive with a protective film on the front. Remove the damaged decal and thoroughly clean surface before installing a new decal. Simply peel off the back, and press new decal onto surface.

NOTICE

PLACARDS AND DECALS CAN BE ORDERED BY USING PART NUMBERS LOCATED BY EACH PLACARD OR DECAL. (SEE FIGURE4-5 DANGER AND WARNING DECAL AND PLACARD LOCATION.)




Figure 4-5 Danger and Warning Decal Location

① 09630010
BA14J-AWD

① 09630011
BA16J-AWD

⑥ 09210016

AERIAL WORK PLATFORM

This product complies with Australian Standard AS/NZS1418.10:2011

Model No: _____

Serial No: _____

Date of Manufacture: _____

Unladen Mass: _____

Rated Capacity: _____

No. Occupants: _____

Max Manual Force: _____

Max Wind Speed: _____

Max Ground Slope: _____

Voltage/Ampage: _____

Design/Registration No: _____

Rated Capacity of Machine: _____

Commission Date: _____

Zhejiang Dingli Machinery Co., Ltd
No. 1203 Bopu South Rd Lishui
Tianze Deyang, Zhejiang China
Tel: 0086 572 8681888 8681888
Fax: 0086 572 8681888
E-mail: zhdmg@dingli.com
http://www.dingli.com

⑦ 09420013

⚠ DANGER

ELECTROCUTION HAZARD

- THIS MACHINE IS NOT INSULATED.
- MAINTAIN A CLEARANCE OF AT LEAST 10 FEET (3 METERS) BETWEEN ANY PART OF MACHINE OR LOAD AND ANY ELECTRICAL LINE OR APPARATUS CARRYING UP TO 50,000 VOLTS.
- ONE FOOT ADDITIONAL CLEARANCE IS REQUIRED FOR EVERY ADDITIONAL 30,000 VOLTS OR LESS.
- ALLOWANCES MUST BE MADE FOR OPERATOR ERROR, MACHINE DEFLECTION AND ELECTRICAL LINE SWAYING.

⚡ DEATH OR SERIOUS INJURY WILL OCCUR FROM CONTACT OR BEING TOO CLOSE TO ELECTRICAL LINES.

DAILY CHECK LIST

1. CHECK TYRES AND THEIR CONDITION.
2. CHECK BOOM AND AXLE CUT-OUT SWITCHES.
3. CHECK SAFETY PROTECTION ITEMS.
4. CHECK ALL OPERATIONS FOR MALFUNCTION.
5. CHECK BRAKES.
6. ENSURE THAT OPERATION AND SAFETY MANUAL IS WITH THE MACHINE.
7. DO NOT OPERATE A MALFUNCTIONING MACHINE.
8. CHECK THE ENGINE AND DRIVE SPEED CUT-OUT SWITCHES.
9. CHECK THE MAXIMUM OPERATING SLOPE.

⚠ CAUTION

THIS MACHINE MAY BE OPERATED BY TRAINED PERSONNEL ONLY. REFERENCE SHOULD BE MADE TO THE OPERATION AND SAFETY MANUAL TO ENSURE SAFE OPERATION OF THIS MACHINE.

⑩ 09310054
HYDRAULIC

⑪ 09310053

⑫ 09320003
DIESEL

② 09420009

⚠ WARNING

- NEVER FILL THE FUEL TANK WITH THE ENGINE RUNNING. NO SMOKING OR NEAR AN OPEN FLAME.
- GROUND THE FUEL FUNNEL OR NOZZLE AGAINST THE FILTER NECK TO PREVENT SPARKS.
- NEVER OVER FILL THE TANK OR SPILL FUEL.

③ 09310049

④ 09310051

⑤ 09310050

⑧ 09120002

EMERGENCY STOP

⚠ 紧急停止按钮: 发动机熄火
When the engine oil pressure warning indicator light, please stop operation at once!

⑨ 09310052

⑬ 09140009

⑭ 09140007

⑮ 09140008

⑯ 09440093

⚠ DANGER

ELECTROCUTION HAZARD

- THIS MACHINE IS NOT INSULATED.
- MAINTAIN A CLEARANCE OF AT LEAST 10 FEET (3 METERS) BETWEEN ANY PART OF MACHINE OR LOAD AND ANY ELECTRICAL LINE OR APPARATUS CARRYING UP TO 50,000 VOLTS.
- ONE FOOT ADDITIONAL CLEARANCE IS REQUIRED FOR EVERY ADDITIONAL 30,000 VOLTS OR LESS.
- ALLOWANCES MUST BE MADE FOR OPERATOR ERROR, MACHINE DEFLECTION AND ELECTRICAL LINE SWAYING.

⚡ DEATH OR SERIOUS INJURY WILL OCCUR FROM CONTACT OR BEING TOO CLOSE TO ELECTRICAL LINES.

DAILY CHECK LIST

1. CHECK TYRES AND THEIR CONDITION.
2. CHECK BOOM AND AXLE CUT-OUT SWITCHES.
3. CHECK SAFETY PROTECTION ITEMS.
4. CHECK ALL OPERATIONS FOR MALFUNCTION.
5. CHECK BRAKES.
6. ENSURE THAT OPERATION AND SAFETY MANUAL IS WITH THE MACHINE.
7. DO NOT OPERATE A MALFUNCTIONING MACHINE.
8. CHECK THE ENGINE AND DRIVE SPEED CUT-OUT SWITCHES.
9. CHECK THE MAXIMUM OPERATING SLOPE.

230kg MAX
+70kg

400N MAX

12.5m/s MAX

⑰ 09140012

⑱ 09140010

⑲ 09440057

⑳ 09440059

㉑ 09420005

㉒ 09420011

㉓ 09440055

㉔ 09340016

㉕ 09340001

㉖ 09910004

㉗ 09440100

㉘ 09340016

㉙ 09340001

㉚ 09440100

㉛ 09440093

⚠ WARNING

DEATH OR INJURY

COULD RESULT IF FOOT SWITCH IS DISABLED, BLOCKED OR INOPERATIVE.

㉜ 09440057

㉝ 09440059

㉞ 09420005

㉟ 09420011

㊱ 09440055

㊲ 09340016

㊳ 09340001

㊴ 09440100

㊵ 09440093

㊶ 09440057

㊷ 09440059

㊸ 09420005

㊹ 09420011

㊺ 09440055

㊻ 09340016

㊼ 09340001

㊽ 09440100

㊾ 09440093

㊿ 09440057

Ⓚ 09440059

Ⓛ 09420005

Ⓜ 09420011

Ⓨ 09440055

Ⓩ 09340016

ⓐ 09340001

ⓑ 09440100

ⓓ 09440093

ⓔ 09440057

ⓖ 09440059

ⓗ 09420005

ⓘ 09420011

ⓙ 09440055

ⓚ 09340016

ⓛ 09340001

ⓜ 09440100

ⓞ 09440093

ⓟ 09440057

ⓠ 09440059

ⓡ 09420005

ⓢ 09420011

ⓤ 09440055

ⓦ 09340016

ⓧ 09340001

ⓨ 09440100

ⓩ 09440093

⓫ 09440057

⓬ 09440059

⓭ 09420005

⓮ 09420011

⓯ 09440055

⓰ 09340016

⓱ 09340001

⓲ 09440100

⓴ 09440093

⓵ 09440057

⓶ 09440059

⓷ 09420005

⓸ 09420011

⓹ 09440055

⓺ 09340016

⓻ 09340001

⓼ 09440100

⓾ 09440093

⓿ 09440057

Ⓚ 09440059

Ⓛ 09420005

Ⓜ 09420011

Ⓨ 09440055

Ⓩ 09340016

ⓐ 09340001

ⓑ 09440100

ⓓ 09440093

ⓔ 09440057

ⓖ 09440059

ⓗ 09420005

ⓘ 09420011

ⓙ 09440055

ⓚ 09340016

ⓛ 09340001

ⓜ 09440100

ⓞ 09440093

ⓟ 09440057

ⓠ 09440059

ⓡ 09420005

ⓢ 09420011

ⓤ 09440055

ⓦ 09340016

ⓧ 09340001

ⓨ 09440100

ⓩ 09440093

⓫ 09440057

⓬ 09440059

⓭ 09420005

⓮ 09420011

⓯ 09440055

⓰ 09340016

⓱ 09340001

⓲ 09440100

⓴ 09440093

⓵ 09440057

⓶ 09440059

⓷ 09420005

⓸ 09420011

⓹ 09440055

⓺ 09340016

⓻ 09340001

⓼ 09440100

⓾ 09440093

⓿ 09440057

Ⓚ 09440059

Ⓛ 09420005

Ⓜ 09420011

Ⓨ 09440055

Ⓩ 09340016

ⓐ 09340001

ⓑ 09440100

ⓓ 09440093

ⓔ 09440057

ⓖ 09440059

ⓗ 09420005

ⓘ 09420011

ⓙ 09440055

ⓚ 09340016

ⓛ 09340001

ⓜ 09440100

ⓞ 09440093

ⓟ 09440057

ⓠ 09440059

ⓡ 09420005

ⓢ 09420011

ⓤ 09440055

ⓦ 09340016

ⓧ 09340001

ⓨ 09440100

ⓩ 09440093

⓫ 09440057

⓬ 09440059

⓭ 09420005

⓮ 09420011

⓯ 09440055

⓰ 09340016

⓱ 09340001

⓲ 09440100

⓴ 09440093

⓵ 09440057

⓶ 09440059

⓷ 09420005

⓸ 09420011

⓹ 09440055

⓺ 09340016

⓻ 09340001

⓼ 09440100

⓾ 09440093

⓿ 09440057

Ⓚ 09440059

Ⓛ 09420005

Ⓜ 09420011

Ⓨ 09440055

Ⓩ 09340016

ⓐ 09340001

ⓑ 09440100

ⓓ 09440093

ⓔ 09440057

ⓖ 09440059

ⓗ 09420005

ⓘ 09420011

ⓙ 09440055

ⓚ 09340016

ⓛ 09340001

ⓜ 09440100

ⓞ 09440093

ⓟ 09440057

ⓠ 09440059

ⓡ 09420005

ⓢ 09420011

ⓤ 09440055

ⓦ 09340016

ⓧ 09340001

ⓨ 09440100

ⓩ 09440093

⓫ 09440057

⓬ 09440059

⓭ 09420005

⓮ 09420011

⓯ 09440055

⓰ 09340016

⓱ 09340001

⓲ 09440100

⓴ 09440093

⓵ 09440057

⓶ 09440059

⓷ 09420005

⓸ 09420011

⓹ 09440055

⓺ 09340016

⓻ 09340001

⓼ 09440100

⓾ 09440093

⓿ 09440057

Ⓚ 09440059

Ⓛ 09420005

Ⓜ 09420011

Ⓨ 09440055

Ⓩ 09340016

ⓐ 09340001

ⓑ 09440100

ⓓ 09440093

ⓔ 09440057

ⓖ 09440059

ⓗ 09420005

ⓘ 09420011

ⓙ 09440055

ⓚ 09340016

ⓛ 09340001

ⓜ 09440100

ⓞ 09440093

ⓟ 09440057

ⓠ 09440059

ⓡ 09420005

ⓢ 09420011

ⓤ 09440055

ⓦ 09340016

ⓧ 09340001

ⓨ 09440100

ⓩ 09440093

⓫ 09440057

⓬ 09440059

⓭ 09420005

⓮ 09420011

⓯ 09440055

⓰ 09340016

⓱ 09340001

⓲ 09440100

⓴ 09440093

⓵ 09440057

⓶ 09440059

⓷ 09420005

⓸ 09420011

⓹ 09440055

⓺ 09340016

⓻ 09340001

⓼ 09440100

⓾ 09440093

⓿ 09440057

Ⓚ 09440059

Ⓛ 09420005

Ⓜ 09420011

Ⓨ 09440055

Ⓩ 09340016

ⓐ 09340001

ⓑ 09440100

ⓓ 09440093

ⓔ 09440057

ⓖ 09440059

ⓗ 09420005

ⓘ 09420011

ⓙ 09440055

ⓚ 09340016

ⓛ 09340001

ⓜ 09440100

ⓞ 09440093

ⓟ 09440057

ⓠ 09440059

ⓡ 09420005

ⓢ 09420011

ⓤ 09440055

ⓦ 09340016

ⓧ 09340001

ⓨ 09440100

ⓩ 09440093

⓫ 09440057

⓬ 09440059

⓭ 09420005

⓮ 09420011

⓯ 09440055

⓰ 09340016

⓱ 09340001

⓲ 09440100

⓴ 09440093

⓵ 09440057

⓶ 09440059

⓷ 09420005

⓸ 09420011

⓹ 09440055

⓺ 09340016

⓻ 09340001

⓼ 09440100

⓾ 09440093

⓿ 09440057

Ⓚ 09440059

Ⓛ 09420005

Ⓜ 09420011

Ⓨ 09440055

Ⓩ 09340016

ⓐ 09340001

ⓑ 09440100

ⓓ 09440093

ⓔ 09440057

ⓖ 09440059

ⓗ 09420005

ⓘ 09420011

ⓙ 09440055

ⓚ 09340016

ⓛ 09340001

ⓜ 09440100

ⓞ 09440093

ⓟ 09440057

ⓠ 09440059

ⓡ 09420005

ⓢ 09420011

ⓤ 09440055

ⓦ 09340016

ⓧ 09340001

ⓨ 09440100

ⓩ 09440093

⓫ 09440057

⓬ 09440059

⓭ 09420005

⓮ 09420011

⓯ 09440055

⓰ 09340016

⓱ 09340001

⓲ 09440100

⓴ 09440093

⓵ 09440057

⓶ 09440059

⓷ 09420005

⓸ 09420011

⓹ 09440055

⓺ 09340016

⓻ 09340001

⓼ 09440100

⓾ 09440093

⓿ 09440057

Ⓚ 09440059

Ⓛ 09420005

Ⓜ 09420011

Ⓨ 09440055

Ⓩ 09340016

ⓐ 09340001

ⓑ 09440100

ⓓ 09440093

ⓔ 09440057

ⓖ 09440059

ⓗ 09420005

ⓘ 09420011

ⓙ 09440055

ⓚ 09340016

ⓛ 09340001

ⓜ 09440100

ⓞ 09440093

ⓟ 09440057

ⓠ 09440059

ⓡ 09420005

ⓢ 09420011

ⓤ 09440055

ⓦ 09340016

ⓧ 09340001

ⓨ 09440100

ⓩ 09440093

⓫ 09440057

⓬ 09440059

⓭ 09420005

⓮ 09420011

⓯ 09440055

⓰ 09340016

⓱ 09340001

⓲ 09440100

⓴ 09440093

⓵ 09440057

⓶ 09440059

⓷ 09420005

⓸ 09420011

⓹ 09440055

⓺ 09340016

⓻ 09340001

⓼ 09440100

⓾ 09440093

⓿ 09440057

Ⓚ 09440059

Ⓛ 09420005

Ⓜ 09420011

Ⓨ 09440055

Ⓩ 09340016

ⓐ 09340001

ⓑ 09440100

ⓓ 09440093

ⓔ 09440057

ⓖ 09440059

ⓗ 09420005

ⓘ 09420011

ⓙ 09440055

ⓚ 09340016

ⓛ 09340001

ⓜ 09440100

ⓞ 09440093

ⓟ 09440057

ⓠ 09440059

ⓡ 09420005

ⓢ 09420011

ⓤ 09440055

ⓦ 09340016

ⓧ 09340001

ⓨ 09440100

ⓩ 09440093

⓫ 09440057

⓬ 09440059

⓭ 09420005

⓮ 09420011

⓯ 09440055

⓰ 09340016

⓱ 09340001

⓲ 09440100

⓴ 09440093

⓵ 09440057

⓶ 09440059

⓷ 09420005

⓸ 09420011

⓹ 09440055

⓺ 09340016

⓻ 09340001

⓼ 09440100

⓾ 09440093

⓿ 09440057

Ⓚ 09440059

Ⓛ 09420005

Ⓜ 09420011

Ⓨ 09440055

Ⓩ 09340016

ⓐ 09340001

ⓑ 09440100

ⓓ 09440093

ⓔ 09440057

ⓖ 09440059

ⓗ 09420005

ⓘ 09420011

ⓙ 09440055

ⓚ 09340016

ⓛ 09340001

ⓜ 09440100

ⓞ 09440093

ⓟ 09440057

ⓠ 09440059

ⓡ 09420005

ⓢ 09420011

ⓤ 09440055

ⓦ 09340016

ⓧ 09340001

ⓨ 09440100

ⓩ 09440093

⓫ 09440057

⓬ 09440059

⓭ 09420005

⓮ 09420011

⓯ 09440055

⓰ 09340016

⓱ 09340001

⓲ 09440100

⓴ 09440093

⓵ 09440057

⓶ 09440059

⓷ 09420005

⓸ 09420011

⓹ 09440055

⓺ 09340016

⓻ 09340001

⓼ 09440100

⓾ 09440093

⓿ 09440057

Ⓚ 09440059

Ⓛ 09420005

Ⓜ 09420011

Ⓨ 09440055

Ⓩ 09340016

ⓐ 09340001

ⓑ 09440100

ⓓ 09440093

ⓔ 09440057

ⓖ 09440059

ⓗ 09420005

ⓘ 09420011

ⓙ 09440055

ⓚ 09340016

ⓛ 09340001

ⓜ 09440100

ⓞ 09440093

ⓟ 09440057

ⓠ 09440059

ⓡ 09420005

ⓢ 09420011

ⓤ 09440055

ⓦ 09340016

ⓧ 09340001

ⓨ 09440100

ⓩ 09440093

⓫ 09440057

⓬ 09440059

⓭ 09420005

⓮ 09420011

⓯ 09440055

⓰ 09340016

⓱ 09340001

⓲ 09440100

⓴ 09440093

⓵ 09440057

⓶ 09440059

⓷ 09420005

⓸ 09420011

⓹ 09440055

⓺ 09340016

⓻ 09340001

⓼ 09440100

⓾ 09440093

⓿ 09440057

Ⓚ 09440059

Ⓛ 09420005

Ⓜ 09420011

Ⓨ 09440055

Ⓩ 09340016

ⓐ 09340001

ⓑ 09440100

ⓓ 09440093

ⓔ 09440057

ⓖ 09440059

ⓗ 09420005

ⓘ 09420011

ⓙ 09440055

ⓚ 09340016

ⓛ 09340001

ⓜ 09440100

ⓞ 09440093

ⓟ 09440057

ⓠ 09440059

ⓡ 09420005

ⓢ 09420011

ⓤ 09440055

ⓦ 09340016

ⓧ 09340001

ⓨ 09440100

ⓩ 09440093

⓫ 09440057

⓬ 09440059

⓭ 09420005

⓮ 09420011

⓯ 09440055

⓰ 09340016

⓱ 09340001

⓲ 09440100

⓴ 09440093

⓵ 09440057

⓶ 09440059

⓷ 09420005

⓸ 09420011

⓹ 09440055

Table 4-3 the description for the placard and decal table

| No. | Parts No. | Description | Qty. | Remark |
|-----|-----------|--|------|-----------|
| 1 | 09630010 | Decal, Label-BA14J-AWD | 1 | BA14J-AWD |
| | 09630011 | Decal, Label-BA16J-AWD | 1 | BA16J-AWD |
| 2 | 09420009 | Decal, Warning-Filling diesel warning | 1 | |
| 3 | 09310049 | Decal, Instructions-Lift point | 4 | |
| 4 | 09310051 | Decal, Instructions-Directional arrows | 4 | |
| 5 | 09310050 | Decal, Instructions-Tie down point | 4 | |
| 6 | 09210016 | Nameplate, Manufacturer serial number | 1 | |
| 7 | 09420013 | Decal, Warning-Electrocution hazard | 1 | |
| 8 | 09120002 | Decal, Ground control panel | 1 | |
| 9 | 09310052 | Decal, Instructions-Highest oil level | 1 | |
| 10 | 09310054 | Decal, Instructions-Hydraulic | 1 | |
| 11 | 09310053 | Decal, Instructions-Lowest oil level | 1 | |
| 12 | 09320003 | Decal, Instructions-Diesel | 1 | |
| 13 | 09140009 | Decal, Platform control panel | 1 | |
| 14 | 09140007 | Decal, Platform control panel | 1 | |
| 15 | 09440092 | Decal, Danger-General safety rules | 1 | |
| 16 | 09140011 | Decal, Platform control panel | 1 | |
| 17 | 09140012 | Decal, Emergency stop panel | 1 | |
| 18 | 09140008 | Decal, Platform control panel | 1 | |
| 19 | 09140010 | Decal, Platform control panel | 1 | |
| 20 | 09440059 | Decal, Label-Lanyard anchorage point | 4 | |
| 21 | 09440057 | Decal, Warning-Footswitch | 1 | |
| 22 | 09420005 | Decal, Warning-Crushing hazard | 5 | |
| 23 | 09440055 | Decal, Label-Capacity 230kg | 1 | |
| 24 | 09340016 | Decal, Instructions-Open/close | 1 | |
| 25 | 09340001 | Decal, Notice-Keep the manual with the machine | 1 | |
| 26 | 09910004 | Decal, Label-4x4 | 2 | |

| No. | Parts No. | Description | Qty. | Remark |
|-----|-----------|--|------|--------|
| 27 | 09440100 | Decal, Warning-Refill engine oil in time | 1 | |
| 28 | 09420011 | Decal, Caution-High temperature | 1 | |
| 29 | 09930004 | Decal, Label-Apollo | 1 | |

Operation Instruction

Section 5

5.1 Description

This machine is a self-propelled hydraulic lift equipped with a work platform on the end of an elevating, articulating and rotating boom. Vibrations emitted by these machines are not hazardous to an operator in the work platform. The machine can be used to position personnel with their tools and supplies at position above ground level and can be used to reach work areas located above and over machinery or equipment.

A full and detailed implementation of EN ISO 13849-1/2 is correctly applied on our MEWP design. SISTEMA, a software tool for PL Calculation Tool, is also used to perform some relatively straightforward calculations on subsystem to determine the overall PL of the system. Reliability data, diagnostic coverage [DC], the system architecture [Category], common cause failure and, where relevant, requirements for software are used to assess the PL to comply with PLr of SRP/CS in Clause 5.11 of EN 280.

The primary operator control station is in the platform. From this control station, the operator can drive and steer the machine in both forward and reverse directions. The operator can raise or lower the boom or swing the boom to the left or right. Standard boom swing is 360 degree continuous left and right of the stowed position. The machine has a **Ground Control Station** which will override the Platform Control Station. Ground Controls operate boom lift and swing, and are to be used in an emergency to lower the platform to the ground should the operator in the platform be unable to do so. The Ground Control is also to be used in Pre-Start Inspection.

Instruction and hazard warnings are posted adjacent to both operator control stations and at other places on the machine. It is extremely important that operators know what instructions and warnings are placed on the machine, and review these periodically so that they are fresh in their minds.

There are efficient and safe operation in accordance with warnings on the machine, in the Operation & Maintenance Manual, and all jobsite and government rules and regulations. As with any type of machinery, the operator is very important to efficient and safe operation. It is absolutely necessary that the machine be regularly maintained in accordance with this manual and the machine Service and Maintenance manual, and that any evidence of lack of maintenance, malfunction, excessive wear, damage or modification to the machine be reported immediately to the machine owner or the jobsite supervisor or safety manager and that the machine be taken out of service until all discrepancies are corrected.

The machine is not intended to be used to lift material other than supplies which personnel in the platform require to do their job. Supplies or tools which extend outside the platform are prohibited. It must not be used as a forklift, crane, and support for overhead structure, or to push or pull another object.

The machine is equipped with an auxiliary battery operated power unit which will provide hydraulic power in the event of a primary engine power loss. Auxiliary power can be controlled from either the Platform Control Station or the Ground Control Station. Follow the instructions placed at the control stations.

The machine is hydraulically powered using hydraulic motors and cylinders for various machine motions. The hydraulic components are controlled by electrically activated hydraulic valves using switches and control levers. The speeds of functions controlled by control levers are variable from zero to maximum speed depending upon the position of the control lever. Functions controlled by toggle switches are either on or off. A foot operated switch in the platform must be depressed before any controls will function and provides a means of emergency stop when the operator's foot is removed from the footswitch.

The machine Lift is a two wheel drive or four wheel drive available machine with drive power being supplied by a hydraulic motor for each drive wheel. Each drive wheel is supplied with a hydraulically released, spring-applied brake. These brakes are automatically applied any time the Drive Control lever is returned to the neutral position

The unrestricted capacity of the machine is 230 kg. This means that with a platform load of 230 kg or less, the platform may be positioned anywhere the boom will reach.

5.2 Operating Characteristics and Limitations

Capacities

The boom can be raised above horizontal with or without any load in platform, if:

- 1) Machine is positioned on a smooth, firm and level surface.
- 2) Load is within manufacturer's rated capacity.
- 3) All machine systems are functioning properly.
- 4) Proper tire pressure (for pneumatic tire).
- 5) Machine is as originally equipped from Dingli Co., Ltd.

Stability

Machine stability is based on two (2) conditions which are called FORWARD and BACKWARD stability. The machine's position of least FORWARD stability is shown in (See Figure5-1.), and its position of least BACKWARD stability is shown in (See Figure 5-2.)



TO AVOID FORWARD OR BACKWARD TIPPING, DO NOT OVERLOAD MACHINE OR OPERATE THE MACHINE ON AN OUT-OF-LEVEL SURFACE.




Figure 5-1 Position of Least Forward Stability




Figure 5-2 Position of Least Backward Stability

5.3 Engine Operation

NOTICE

INITIAL STARTING SHOULD ALWAYS BE PERFORMED FROM THE GROUND CONTROL STATION.

CAUTION

IF ENGINE FAILS TO START PROMPTLY, DO NOT CRANK FOR AN EXTENDED TIME. SHOULD ENGINE FAIL TO START AGAIN, ALLOW STARTER TO "COOL OFF" FOR 2-3 MINUTES. IF ENGINE FAILS AFTER SEVERAL ATTEMPTS, REFER TO ENGINE MAINTENANCE MANUAL.

NOTICE

DIESEL ENGINES ONLY: AFTER TURNING ON IGNITION, OPERATOR MUST WAIT UNTIL GLOW PLUG INDICATOR LIGHT GOES OUT BEFORE CRANKING ENGINE.

Starting Procedure

- 1) Turn key of SELECT switch to GROUND. Position POWER/EMERGENCY STOP switch to ON, then push the ENGINE START switch until engine starts.

CAUTION

ALLOW ENGINE TO WARM-UP FOR A FEW MINUTES AT LOW SPEED BEFORE APPLYING ANY LOAD.

- 2) After engine has had sufficient time to warm up, shut engine off.
- 3) Turn SELECT switch to PLATFORM.
- 4) From Platform, pull the mushroom of POWER/EMERGENCY STOP switch out, then push the ENGINE START switch until engine starts.

NOTICE

FOOTSWITCH MUST BE IN RELEASED (UP) POSITION BEFORE STARTER WILL OPERATE. IF STARTER OPERATES WITH FOOTSWITCH IN THE DEPRESSED POSITION, DO NOT OPERATE MACHINE.

Shutdown Procedure

CAUTION

IF AN ENGINE MALFUNCTION CAUSES AN UNSCHEDULED SHUTDOWN, DETERMINE THE CAUSE AND CORRECT IT BEFORE RESTARTING THE ENGINE.

- 1) Remove all loads and allow engine to operate at low speed for 3-5 minutes; this allows further reduction of internal engine temperature.
- 2) Push POWER/EMERGENCY STOP switch in.
- 3) Turn MASTER switch to off.

Refer to Engine Manufacturer's manual for detailed information.

5.4 Traveling (Driving) Operation

⚠ WARNING

DO NOT DRIVE WITH BOOM EXTENDED OR ABOVE HORIZONTAL EXCEPT ON A SMOOTH, FIRM AND LEVEL SURFACE.


TO AVOID LOSS OF TRAVEL CONTROL OR "TIP OVER", DO NOT DRIVE MACHINE ON GRADES EXCEEDING THOSE SPECIFIED ON THE SERIAL NUMBER TAG OR AS NOTED IN THE OPERATORS MANUAL.

DO NOT DRIVE ON SIDESLOPES WHICH EXCEED 5 DEGREES.

USE EXTREME CAUTION WHEN DRIVING IN REVERSE AND AT ALL TIMES WHEN THE PLATFORM IS ELEVATED.

TRAVEL GRADES WITH DRIVE SPEED/TORQUE SELECT SWITCH IN THE FORWARD POSITION. USE CAUTION WHEN DRIVING IN REVERSE AND WHEN DRIVING WITH PLATFORM ELEVATED, ESPECIALLY WHEN DRIVING WITH ANY PART OF MACHINE WITHIN 6 FEET (2 M) OF AN OBSTRUCTION.

BEFORE DRIVING, MAKE SURE BOOM IS POSITIONED OVER REAR DRIVE AXLE. IF BOOM IS OVER FRONT WHEELS, STEER AND DRIVE CONTROLS WILL BE REVERSED.



Do not drive the machine on grades and sideslopes exceeding those specified on the technical specification.

Traveling Forward and Reverse

- 1) With the engine running, activate footswitch.
- 2) Position Drive controller to FORWARD or REVERSE as desired.

5.5 Steering Operation

- 1) With the engine running, activate footswitch.
- 2) Position thumb switch on Drive/Steer controller to RIGHT for steering right, or to LEFT for steering left.

5.6 Platform Operation

Platform Level Adjustment

WARNING

ONLY USE THE PLATFORM LEVELING OVERRIDE FUNCTION FOR SLIGHT LEVELING OF THE PLATFORM. INCORRECT USE COULD CAUSE THE LOAD/OCCUPANTS TO SHIFT OR FALL. FAILURE TO DO SO COULD RESULT IN DEATH OR SERIOUS INJURY.

This switch is used to adjust the platform level in situations such as ascending/descending a grade.

- 1) Turn the Ground and Platform Console Selecting Switch to select Ground or Platform Console.
- 2) Activate footswitch (platform control station) or depress the Enabling Switch and hold on.
- 3) Leveling Up, Position the Platform Toggle Switch Level to Up and hold until platform is level.
- 4) Leveling Down, Position the Platform Level Toggle Switch Level to Down and hold until the platform is level.

Platform Rotation

- 1) Turn the Ground and Platform Console Selecting Switch to select Ground or Platform Console.
- 2) Activate footswitch (platform control station) or depress the Enabling Switch and hold on.
- 3) To rotate the platform to the left or right, use the Platform Rotate control switch to select the direction and hold until desired position is reached.

5.7 Turntable Swinging Operation

WARNING

DO NOT SWING OR RAISE BOOM ABOVE HORIZONTAL WHEN MACHINE IS OUT OF LEVEL.

DO NOT DEPEND ON TILT ALARM AS A LEVEL INDICATOR FOR THE CHASSIS.

TO AVOID SERIOUS INJURY, DO NOT OPERATE MACHINE IF ANY CONTROL LEVER OR TOGGLE SWITCH CONTROLLING PLATFORM MOVEMENT DOES NOT RETURN TO THE 'OFF' OR NEUTRAL POSITION WHEN RELEASED.

IF THE PLATFORM DOES NOT STOP WHEN A CONTROL SWITCH OR LEVER IS RELEASED, REMOVE FOOT FROM FOOTSWITCH OR USE EMERGENCY STOP SWITCH TO STOP THE MACHINE.

Swinging the turntable

- 1) Turn the Ground and Platform Console Selecting Switch to select Ground or Platform Console.
- 2) Activate footswitch (platform control station) or depress the Enabling Switch and hold on.
- 3) To swing boom, use SWING control switch to select RIGHT or LEFT direction.

NOTICE

WHEN SWINGING THE BOOM MAKE SURE THERE IS AMPLE ROOM FOR THE BOOM TO CLEAR SURROUNDING WALLS, PARTITIONS AND EQUIPMENT.

5.8 Boom Operation

Raising and Lowering the Lower and Mid Boom

Raising and Lowering the Lower and Mid Boom

- 1) Turn the Ground and Platform Console Selecting Switch to select Ground or Platform Console.
- 2) Activate footswitch (platform control station) or depress the Enabling Switch and hold on.
- 3) To raise or lower the Lower Boom, use Lower Boom Lift switch to select UP or DOWN movement.


⚠ WARNING

WHEN RAISE AND LOWER BOOM, CHECK FOR SMOOTH OPERATION. CHECK BOOM UPRIGHT TILTING FOR PROPER SYNCHRONIZATION. IF THE UPRIGHT IS TILTED OR THE BOOM WILL NOT FULLY LOWER, ADJUSTMENT SHOULD BE DONE ACCORDING TO THE BOOM SYNCHRONIZING PROCEDURE BELOW:


Boom Synchronizing Procedure

If the lower boom does not fully lower, use the following procedure.

- 1) Remove all personnel from the platform.
- 2) Pull out the red EMS (emergency stop) knob located on the ground control station.
- 3) Turn the platform/ground select switch to the ground control position.
- 4) If applicable, start the engine.
- 5) Pull and hold out the red re-level knob on the synchronizing valve located beside the main control valve.



- 6) From the ground controls, activate the lift control switch, and raise the lower boom approximately 6 feet (2 m).
- 7) After raising the lower boom, release the red knob.



- 8) Activate the lift control switch and fully lower the boom and continue to hold down the switch for an additional 5 seconds.
- 9) Repeat steps 5 thru 8 if necessary.

Telescoping the Main Boom

- 1) Turn the Ground and Platform Console Selecting Switch to select Ground or Platform Console.
- 2) Activate footswitch (platform control station) or depress the Enabling Switch and hold on.
- 3) To extend or retract the main boom, use the Main Telescope Control Switch to select IN or OUT movement.

Raising and Lowering the Main (Upper) Boom

- 1) Turn the Ground and Platform Console Selecting Switch to select Ground or Platform Console.
- 2) Activate footswitch (platform control station) or depress the Enabling Switch and hold on.
- 3) To raise or lower the Upper Boom, use Upper Boom Lift switch to select UP or DOWN movement.

5.9 Jib Operation

- 1) Turn the Ground and Platform Console Selecting Switch to select Ground or Platform Console.
- 2) Activate footswitch (platform control station) or depress the Enabling Switch and hold on.
- 3) To lift up the Jib Boom or down, use The Jib Boom Up and Down Controller to select direction and hold until desired position is reached.

5.10 Auxiliary Pump Operation

NOTICE

WHEN OPERATING ON AUXILIARY POWER, DO NOT OPERATE MORE THAN ONE FUNCTION AT THE SAME TIME. SIMULTANEOUS OPERATION CAN OVERLOAD THE AUXILIARY PUMP MOTOR.

The main function of auxiliary power is to lower the platform in the event of primary power failure. Determine the reason for primary power failure and have the problem corrected by a certified service technician. Operate as follows:

To activate auxiliary power from the platform control station:

- 1) Position PLATFORM/GROUND SELECT KEY SWITCH to PLATFORM.
- 2) Position POWER/EMERGENCY STOP switch to ON.
- 3) Depress and hold footswitch.
- 4) Position AUXILIARY POWER switch to ON and hold.
- 5) Operate appropriate control switch, lever or controller for desired function and hold.
- 6) Release AUXILIARY POWER switch, selected control switch, lever or controller, and

footswitch.

- 7) Position POWER/EMERGENCY STOP switch to OFF.

To activate auxiliary power from the ground control station:

- 1) Position PLATFORM/GROUND SELECT KEY SWITCH to GROUND.
- 2) Position POWER/EMERGENCY STOP switch to ON.
- 3) Position AUXILIARY POWER switch to ON and hold.
- 4) Operate appropriate control switch or controller for desired function and hold.
- 5) Release AUXILIARY POWER switch, and appropriate control switch or controller.
- 6) Position POWER/EMERGENCY STOP switch to OFF.

5.11 Oscillating Axle Lockout Test (If Equipped)

NOTICE

LOCKOUT SYSTEM TEST MUST BE PERFORMED QUARTERLY, ANY TIME A SYSTEM COMPONENT IS REPLACED, OR WHEN IMPROPER SYSTEM OPERATION IS SUSPECTED.

Refer to **Section 3.3**, Oscillating Axle Lockout Test (If Equipped) for procedure.

5.12 Shut Down and Parking

- 1) Drive machine to a reasonably well protected area.
- 2) Be sure the main boom is fully retracted and lowered over rear drive axle.
- 3) Remove all load and allow engine to operate 3-5 minutes at LOW setting to permit reduction of internal engine temperatures.
- 4) At Ground Controls, turn KEY SELECT switch to OFF position. Push in the Emergency Stop. Remove key.
- 5) If necessary, cover Platform Control console to protect instruction placards, warning decals and operating controls from hostile environment.

5.13 Lifting and Tie Down

Lifting Operation

- 1) Refer to the Serial Number Tag, to make sure the Gross Vehicle Weight.
- 2) Place the boom in the stowed position.
- 3) Remove all loose items from the machine.
- 4) Properly adjust the rigging to prevent damage to the machine and so the machine remains level.

If it becomes necessary to lift the machine using an overhead or mobile crane, it is very important that the lifting devices are attached only to the designated lifting eyes. (See Figure 5-3. Lifting Diagram)

NOTICE

LIFTING EYES ARE PROVIDED AT THE FRONT AND REAR IN THE FRAME SLAB. EACH OF THE FOUR CHAINS OR SLINGS USED FOR LIFTING MACHINE MUST BE ADJUSTED INDIVIDUALLY SO MACHINE REMAINS LEVEL WHEN ELEVATED.




Figure 5-3 Lifting Diagram

Tie Down Operation

NOTICE

WHEN TRANSPORTING MACHINE, BOOM MUST BE IN THE STOWED MODE AND MACHINE SECURELY TIED DOWN TO TRUCK OR TRAILER DECK. FOUR TIE DOWN EYES ARE PROVIDED IN THE FRAME SLAB, ONE AT EACH CORNER OF THE MACHINE. (SEE FIGURE 5-3. AND FIGURE 5-4.)

- 1) Place the boom in the stowed position.
- 2) Remove all loose items from the machine.
- 3) Secure the chassis and the platform using straps or chains of adequate strength.




Figure 5-4 Tie Down Diagram

5.14 Towing Operation

▲ WARNING

RUNAWAY VEHICLE/MACHINE HAZARD. MACHINE HAS NO TOWING BRAKES. TOWING VEHICLE MUST BE ABLE TO CONTROL MACHINE AT ALL TIMES. ON-HIGHWAY TOWING NOT PERMITTED. FAILURE TO FOLLOW INSTRUCTIONS COULD CAUSE SERIOUS INJURY OR DEATH.

MAXIMUM TOWING SPEED 5 M.P.H. (8 K.M.H.) FOR NO LONGER THAN 30-45 MINUTES.

MAXIMUM TOWING GRADE 25%.

Prior to Towing

Prior to towing the machine, complete the following:

▲ CAUTION

DO NOT TOW MACHINE WITH ENGINE OPERATING OR DRIVE HUBS ENGAGED.

- 1) Retract, lower and position boom over rear drive wheels in line with direction of travel.

- 2) Disconnect drive hubs by inverting disconnect cap. (See Figure 5-5.) After towing the machine, complete the following:
- 3) Reconnect drive hubs by inverting disconnect cap. (See Figure 5-5.)




Figure 5-5 Disengage the Drive Hub

Emergency Procedures

Section 6


6.1 General

This section provides information on the procedures to be followed and on the systems and controls to be used in the event an emergency situation is encountered during machine operation. Prior to operation of the machine and periodically thereafter, the entire operating manual, including this section, should be reviewed by all personnel whose responsibilities include any work or contact with the machine.

6.2 Emergency Towing Procedures

Towing this machine is prohibited, unless properly equipped. However, provisions for moving the machine, in case of a malfunction or power failure, have been incorporated. The following procedures are to be used **ONLY** for emergency movement to a suitable maintenance area.


- 1) Chock wheels securely.
- 2) Disengage drive hubs by reversing disconnect caps.



- 3) Connect suitable equipment, remove chocks, and move machine.

After moving machine, complete the following procedures:

- 1) Position machine on a firm and level surface.
- 2) Chock wheels securely.
- 3) Engage drive hubs by reversing disconnect caps on hubs.



- 4) Remove chocks from wheels as needed.

6.3 Emergency Controls and Their Locations

6.3.1 Power/Emergency Stop Switches

- 1) There is one of these red mushroom shaped switches at both the *Ground Controls* and *Platform Controls*. When it is depressed it will immediately stop the machine.



CHECK MACHINE DAILY TO MAKE SURE EMERGENCY STOP SWITCH GUARD IS IN PLACE AND THAT GROUND CONTROL INSTRUCTIONS ARE IN PLACE AND LEGIBLE.

- 2) Installed on the Platform Console, this round red switch is pulled up for normal machine functions. In an emergency, push the button to the down position with your palm and machine will immediately stop.

6.3.2 Ground Control Station

The Ground Control Station is located on the right front side of the turntable. The controls on this panel provide the means for overriding the platform controls, and for controlling the boom and swing functions from the ground. Place the KEY SELECT switch to GROUND position and operate the proper switch to lift, swing, or telescope the boom, or level the platform.

6.3.3 Auxiliary Power

A toggle type auxiliary power control switch is located on the platform control station and another is located on the ground control station. Operation of either switch turns on the electrically driven auxiliary hydraulic pump. This should be used in case of failure of the main power plant. When platform control chosen, the auxiliary pump will operate boom lift down, main boom retract, jib lift up and down, turntable rotate, platform swing and level. Otherwise, when ground control chosen, the auxiliary pump will not operate jib lift up and platform swing. The instruction is Refer to Section 5.9.

NOTICE

WHEN OPERATING ON AUXILIARY POWER, DO NOT OPERATE MORE THAN ONE FUNCTION AT THE SAME TIME. SIMULTANEOUS OPERATION CAN OVERLOAD THE AUXILIARY PUMP MOTOR.

6.4 Emergency Operation

6.4.1 Use of Ground Controls

Know how to use the ground controls in an emergency situation.

Ground personnel must be thoroughly familiar with the machine operating characteristics and the ground control functions. Training should include operation of the machine, review and understanding of this section and hands-on operation of the controls in simulated emergencies.

6.4.2 Operator Unable to Control Machine

If the Platform Operator Is Pined, Trapped or Unable to Operate or Control the Machine

⚠ WARNING

DO NOT OPERATE WITH PRIMARY POWER SOURCE (ENGINE OR ELECTRIC MOTOR) IF PERSONS ARE PINNED OR TRAPPED. USE AUXILIARY POWER INSTEAD.

- 1) Operate the machine from ground controls ONLY with the assistance of other personnel and equipment (cranes, overhead hoists, etc.) as may be required to safely remove the danger or emergency condition.
- 2) Other qualified personnel on the platform may use the platform controls with regular or auxiliary power. **DO NOT CONTINUE OPERATION IF CONTROLS DO NOT FUNCTION NORMALLY.**
- 3) Cranes, forklift trucks or other equipment which may be available are to be used to remove platform occupants and stabilize motion of the machine in case machine controls are inadequate or malfunction when used.

6.4.3 Platform or Boom Caught Overhead

If the platform or boom becomes jammed or snagged in overhead structures or equipment, do not continue operation of the machine from either the platform or the ground until the operator and all personnel are safely moved to a secure location. Only then should an attempt be made to free the platform using any necessary equipment and personnel. Do not operate controls to cause one or more wheels to leave the ground.

6.4.4 Post Incident Inspection and Repair

Following any incident, thoroughly inspect the machine and test all functions first from the ground controls, then from the platform controls. Do not lift above 3 m (10 feet) until you are sure that all

damage has been repaired, if required, and that all controls are operating correctly. A cold weather start system in the diesel engine functions automatically to provide starting fluid, as necessary, to the engine. A sensor switch mounted on the engine will permit ether injection when the engine is cold. The sensor will not permit ether injection to a warm engine.

6.5 Incident Notification

It is imperative that Dingli Machinery Co.,Ltd. be notified immediately of any incident involving a Dingli product. Even if no injury or property damage is evident, the factory should be contacted by telephone, fax or email and provided with all necessary details.

It should be noted that failure to notify the manufacturer of an incident involving a Dingli product within 48 hours of such an occurrence may void any warranty consideration on that particular machine.

In China Mainland:

Phone: +86 572 8681766 (8 Am till 4:30PM)

Fax: +86 572 8681700

Email: sales@ccdingli.com

Outside China Mainland:

Phone: +86 572 8681688

Fax: +86 572 8681690

Email: export@cndingli.com

General Maintenance

Section 7

7.1 General

This section of the manual provides additional necessary information to the operator for proper operation and maintenance of this machine. The maintenance portion of this section is intended as information to assist the machine operator to perform daily maintenance tasks only, and does not replace the more thorough Preventive Maintenance and Inspection Schedule. Refer to Perkins Engine Operation and Maintenance Manual for detail maintenance information about the diesel engine.

7.2 Lubrication Specification

Table7-1 Lubrication Specifications

| KEY | SPECIFICATIONS |
|------|---|
| MPG | Multipurpose Grease having a minimum dripping point of 350° F (177° C). Excellent water resistance and adhesive qualities, and being of extreme pressure type. (Timken OK 40 pounds minimum.) |
| EPGL | Extreme Pressure Gear Lube (oil) meeting API service classification GL-5 or MIL-Spec MIL-L-2105 |
| HO | Hydraulic Oil. API service classification GL-3, e.g. Mobil fluid 424. |
| EO | Engine (crankcase) Oil. Gas - API SF, SH, SG class, MIL-L-2104. Diesel - API CC/CD class, MIL-L-2104B/MIL-L-2104C. |
| OGL | Open Gear Lubricant - Mobiltac 375 or equivalent. |

NOTE: It is recommended as a good practice to replace all filters at the same time.

7.3 Lubrication Diagram

Refer to the configure for normally lubrication point and Item

NOTICE

LUBRICATION INTERVALS ARE BASED ON MACHINE OPERATION UNDER NORMAL CONDITIONS. FOR MACHINES USED IN MULTI-SHIFT OPERATIONS AND/OR EXPOSED TO HOSTILE ENVIRONMENTS OR CONDITIONS, LUBRICATION FREQUENCIES MUST BE INCREASED ACCORDINGLY.




Figure 7-1 Operator Maintenance and Lubrication Diagram

7.4 Operator Maintenance

7.4.1 Wheel Bearings

A Wheel Bearings (2WD Only)

| | |
|------------------------|--|
| Lube Point(s) - | Repack |
| Capacity - | A/R |
| Lube - | MPG |
| Interval - | Every 2 years or 1200 hours of operation |

B Wheel Drive Hub

| | |
|------------------------|--|
| Lube Point(s) - | Level/Fill Plug |
| Oil Capacity - | Per Hub about - 17 oz. - 1/2 Full |
| Lube - | EPGL, SAE 90 multipurpose hypoid gear oil- API service classification GL5, Mobile HD85W-90 is recommended. |
| Interval - | Check level every 3 months or 150 hrs of operation; change every 2 years or 1200 hours of operation. |

Replacing the torque hub oil is essential for good machine performance and service life. Failure to replace the torque hub oil at yearly intervals may cause the machine to perform poorly and continued use may cause component damage.

- Elect the drive torque hub to be serviced. Then drive the machine until one of the two draining plugs is at the lowest point.
- Remove both plugs and drain the oil
- Drive the machine until one plug is at the top and the other is at 90 degree.
- Fill the hub with oil from the top hole until the oil level is even with the bottom of the side hole.
- Apply pipe thread sealant to the plugs, then to install the plugs.
- Repeat this procedure for each torque hub.

7.4.2 Lubrication for the Swing Bearing and Worm Gear

Yearly application to lubrication to the turntable bearing (Swing Bearing) and worm drive gear is essential to good machine performance and service life. Continued use of an improperly greased gear will result in component damage.

- 1) Raise the secondary boom and place a safety chock on the secondary boom lift cylinder. Carefully lower the boom onto the lift cylinder safety chock.



CRUSHING HAZARDS. KEEP HANDS AWAY FROM CYLINDER AND ALL MOVING PARTS WHEN LOWERING THE SECONDARY BOOM.

- 2) Located the grease fitting on the inside of the bearing in the middle of the turntable.
- 3) Pump grease into the turntable rotation bearing. Rotate the turntable in increments of 4 to 5 inch(10-13cm) at a time and repeat this step until the entire bearing has been greased.

⚠ CAUTION

DO NOT OVERGREASE END BEARINGS. OVERGREASING BEARINGS WILL RESULT IN BLOWING OUTER SEAL IN HOUSING.

- 4) Remove the safety chock. Lower the boom to the stowed position.
- 5) Locate the grease on the worm drive housing.
- 6) Pump grease into the gear until you see it coming out of the side of the gear housing.
- 7) Grease each tooth on the outside of the turntable rotation bearing.

Lubrication for Swing Bearing (Refer to the Figure 7-1 Item3)

| | |
|------------------------|--|
| Lube Point(s) - | 4 Grease Fittings |
| Capacity - | A/R |
| Lube – | MPG |
| Interval - | Every 3 months or 150 hrs of operation |

Lubrication for the Outer Gear Teeth (Refer to the Figure7-1 Item3)

| | |
|------------------------|---|
| Lube Point(s) - | The Outer Gear Teeth |
| Capacity - | A/R |
| Lube – | OGL |
| Interval - | Every one months or 50 hrs of operation |

Lubrication for the Worm Gear (Refer to the Figure 7-1 Item 2)

| | |
|------------------------|-------------------------------------|
| Lube Point(s) - | 2 Grease Fittings |
| Capacity - | A/R |
| Lube – | MPG |
| Interval - | Every year or 1000 hrs of operation |

Comments - Remove grease fittings and install plugs after greasing

7.4.3 Test and Replace the Hydraulic Oil

Replacement and testing of the hydraulic oil is essential for good machine performance and service life. Dirty oil and suction strainers may cause the machine poorly and continued use may cause components damage. Extremely dirty conditions may require oil changes to be performed more often.

NOTICE

THE MACHINE USE DEXRON EQUIVALENT HYDRAULIC OIL, BEFORE REPLACING THE HYDRAULIC OIL DISTRIBUTOR FOR SPECIFIC LEVELS OF CONTAMINATION TO VERIFY THAT CHANGING THE OIL IS NECESSARY. IF THE HYDRAULIC OIL IS NOT REPLACED AT THE TWO YEAR INSPECTION, TEST THE OIL QUARTERLY. REPLACE THE OIL WHEN IT FAILS THE TEST.

Perform this procedure with the boom in the stowed position.

- 1) Remove the plug from the drain hose on the hydraulic reservoir
- 2) Completely drain the tank into a suitable container. See capacity specifications listed below.
- 3) Rinse out the inside of the tank with a mild solvent.
- 4) Change the Suction port filter net (refer Replace the Suction Filter)
- 5) Change the Return filter element (refer to Replace the Return filter element)
- 6) Change the Charge filter element (refer to Replace the Charge Filter Element)
- 7) Install the plug on the drain port.
- 8) Fill the tank with hydraulic oil use a 10um filter until the fluid is thin the top 2 inches of the sight gauge. Not overfill.
- 9) Disconnect the Port P4 on the Main manifold, block it use a M16*1.5 Plug, and take a suitable container under the port of the hose,
- 10) Start the engine in the Ground Control Station, put the toggle switch forward to raise the main upper boom, take the hose and lead the oil from the cylinder non-rid chamber into the container.
- 11) Stop the engine and reconnect the hose to the P4 port.
- 12) Disconnect the Port P13 on the Main manifold, block it use a M16*1.5 Plug, and take a suitable container under the port of the hose,
- 13) Start the engine in the Ground Control Station, put the up toggle switch to raise the Lower and Mid Boom, take the hose and let the oil from the cylinder non-rid chamber into the container.
- 14) Stop the engine and reconnect the hose to the P13 port.
- 15) Pull up the red re-level knob on the synchronizing valve located beside the main control valve manifold assembly.
- 16) Find the hose connected to the Port T on the synchronizing valve, and disconnect the end fitting which is located on the hydraulic reservoir, and block the port in the reservoir. Then take a suitable container under the hose to accept the oil.
- 17) Start the engine in the Ground Control Station, put the toggle switch lever forward to raise the Lower Boom, take the hose and let the oil from the cylinder non-rid chamber into the

container.

- 18) Stop the engine and reconnect the hose to the P13 port
- 19) Disconnect the Port P15 on the Main manifold, block the port use a M16*1.5 Plug, and take a suitable container under the port of the hose,
- 20) Start the engine in the Ground Control Station, put the toggle switch forward to extend the main upper telescopic boom, take the hose to lead the oil from the cylinder non-rod chamber into the container.
- 21) Stop the engine and reconnect the hose to the P15 port.

7.4.4 Replace the Hydraulic Filters

Replacement of the hydraulic filters is essential for good machine performance and service life. A dirty or clogged filter may cause the machine to perform poorly and continued use may cause component damage. Extremely dirty conditions may require that the filter be replaced more often.

Replace the Suction Filter Procedure:

- 1) Clean the area around the cover of the hydraulic oil reservoir.
- 2) Use a wrench to loose and remove the 10 bolts from the hydraulic oil reservoir cover, move the cover away from the reservoir, then turn the filter element from the adaptor.
- 3) Take a new filter element to screw it onto the filter adaptor.
- 4) Install the cover to hydraulic oil reservoir, and screw down 10 bolts.
- 5) The suction filter element Dingli Part Number is 5899-0913
- 6) Interval—Every 2years or 1200 hours of operation. Remove and clean at time of hydraulic oil change.

Replace the Charge Filter Procedure:

- 1) Clean the area around the oil filter, then remove the filter assembly cover
- 2) pull out the filter element from the filter assembly chamber,
- 3) Install the new filter element to the filter assembly chamber.
- 4) Install the filter assembly cover and tighten it. Clean up any oil that may have spilled during the replacement procedure
- 5) The high pressure filter assembly Dingli Part Number is 5899-0711, and the charge filter element Dingli Part Number is 5899-0811.
- 6) Interval—Change after first 50 hrs, and every 6 months or 300 hrs. thereafter or as indicated by Condition Indicator



Replace the Return Filter Procedure:

- 1) Clean the area around the oil filter, then remove the filter assembly cover use a 4mm wrench.
- 2) pull out the filter element from the filter assembly chamber.
- 3) Install the new filter element to the filter assembly chamber.
- 4) Install the filter assembly cover and tighten it. Clean up any oil that may have spilled during the replacement procedure.
- 5) The return filter assembly Dingli Part Number is 5899-0511, and the return filter element Dingli Part Number is 5899-0611.
- 6) Interval—Change after first 50 hrs, and every 6 months or 300 hrs. Thereafter or as indicated by Condition Indicator.



7.4.5 Replace the Engine Oil

Refer to the Engine Operation and Maintenance Manual for detail information.

7.4.6 Replace the Engine Fuel Filter

Replacing the diesel fuel filter is essential to good engine performance and service life. A dirty or clogged filter may cause the engine to perform poorly and continued use may cause component damage. Extremely dirty conditions may require that the filter be replaced more often. Refer to the Engine Operation and Maintenance Manual for detail information.

! DANGER

ENGINE FUELS ARE COMBUSTIBLE. REPLACE THE FUEL FILTER IN AN OPEN, WELL-VENTILATED AREA AWAY FROM HEATER, SPARKS, FLAMES AND LIGHTED TOBACCO. ALWAYS HAVE AN APPROVED FIRE EXTINGUISHER WITHIN EASY REACH.

! WARNING

NEVER FILL THE FUEL TANK WITH THE ENGINE RUNNING, WHILE SMOKING OR WHEN NEAR AN OPEN FLAME.

NEVER OVER FILL THE TANK OR SPILL FUEL. IF FUEL IS SPILLED, CLEAN IT UP IMMEDIATELY.

BE SURE TO USE THE CORRECT TYPE AND GRADE OF FUEL.

BE SURE TO REPLACE THE FUEL TANK CAP AND GROUND THE FUEL FUNNEL OR NOZZLE AGAINST THE FILTER NECK TO PREVENT SPARKS.

7.4.7 Replace the Water Separator

A Water Separator is installed between the Fuel tank and the Fuel filter to separate the water from the fuel. It is useful to prevent the water enter the fuel system causing the component damaged. Reference the Replace the Engine Filter


Kubota Engine**Engine front**

1

2

1. Fuel Filter


2. Water Separator

Engine back

3

3. Engine Oil Filter

Perkins Engine



1

2

3

1.Engine Oil Filter

2.Water Separator

3.Fuel Filter

7.4.8 Tires & Wheels Maintenance

Tire Damage

For polyurethane foam filled tires, Dingli recommends that when any of the following are discovered, measures must be taken to remove the machine from service immediately and arrangements must be made for replacement of the tire or tire assembly.

- A smooth, even cut through the cord plies which exceeds 3 inches (7.5 cm) in total length.
- Any tears or rips (ragged edges) in the cord plies which exceeds 1 inch (2.5 cm) in any direction.
- Any punctures which exceed 1 inch in diameter.
- any damage to the bead area cords of the tire

If a tire is damaged but is within the above noted criteria, the tire must be inspected on a daily basis to insure the damage has not propagated beyond the allowable criteria.

Tire Replacement

Dingli recommends a replacement tire be the same size, ply and brand as originally installed on the machine. Please refer to the Parts Manual for the part number of the approved tires for a particular machine model. If not using an approved replacement tire, we recommend that replacement tires have the following characteristics:

- Equal or greater ply/load rating and size of original
- Tire tread contact width equal or greater than original

- Wheel diameter, width, and offset dimensions equal to the original
- Approved for the application by the tire manufacturer (including inflation pressure and maximum tire load), unless specifically approved by the manufacture. Do not replace foam filled or ballast filled tire assembly with a pneumatic tire. When selecting and installing a replacement tire, ensure that all tires are inflated to the pressure recommended. Due to size variations between tire brands, both tires on the same axle should be the same.

Wheel Replacement

The rims installed on each product model have been designed for stability requirements which consist of track width, tire pressure, and load capacity. Size changes such as rim width, center piece location, larger or smaller diameter, etc., without written factory recommendations, may result in an unsafe condition regarding stability.

Wheel Installation


It is extremely important to apply and maintain proper mounting torque.

⚠ WARNING

WHEEL NUTS MUST BE INSTALLED AND MAINTAINED AT TORQUE TO PREVENT LOOSE WHEELS, BROKEN STUDS, POSSIBLE DANGEROUS SEPARATION OF WHEEL FROM THE AXLE. TO USE ONLY THE NUTS MATCHED TO THE CONE ANGLE WHEEL.

Tighten the lug nuts to the proper torque to prevent coming loose. Use a torque wrench to tighten fasteners. If you do not have a torque wrench, tighten the fasteners with a lug wrench, then immediately have a service garage tighten the lug nuts to the proper torque. Over-tightening result in breaking the studs or permanently deforming mounting stud holes in the wheels. The proper procedure attaching wheels is as follows:

- 1) Start all nuts by hand to prevent cross threading. NOT use a lubricant on threads or nuts.
- 2) Tighten nuts in the following sequence:



- 3) The tightening of the nuts should be done in stages. Following the recommended sequence tighten nuts per wheel torque chart.

| TORQUE SEQUENCE | | |
|-------------------------|---------------------------|---------------------------|
| 1st Stage | 2nd Stage | 3rd Stage |
| 40 ft. lbs. (55 N·m) | 100 ft. lbs. (130 N·m) | 170 ft. lbs. (255 N·m) |

- 4) Wheel nuts should be torque after first 50 hours of operation and after each wheel removal. Check torque every 3 months or 150 hours of operation.

7.4.9 Battery Maintenance

WARNING

LEAD ACID BATTERIES PRODUCE FLAMMABLE AND EXPLOSIVE TO AVOID INJURY FROM AN EXPLOSION, DO NOT SMOKE OR ALLOW SPARKS OR A FLAME NEAR BATTERY DURING SERVICING. ALWAYS WEAR EYE PROTECTION WHEN SERVICING BATTERIES.

- 1) The battery is maintenance free except for occasional battery terminal cleaning, as noted in the following.
- 2) Remove battery cables from each battery post one at a time, negative first. Clean cables with acid neutralizing solution (e.g. baking soda and water or ammonia) and wire brush. Replace cables and/or cable clamp bolts as required.
- 3) Clean battery post with wire brush then re-connect cable to post. Coat non-contact surfaces with mineral grease or petroleum jelly (Vaseline).
- 4) When all cables and terminal posts have been cleaned, ensure all cables are properly positioned and are not pinched. Close battery compartment cover.

CAUTION

NEVER WORK ON THE ELECTRICAL SYSTEM OF ANY EQUIPMENT UNLESS YOU ARE THOROUGHLY FAMILIAR WITH SYSTEM DETAIL.

NEVER CHECK THE BATTERY BY PLACING A METAL OBJECT ACROSS THE POSTS. SERIOUS BURNS OR AN EXPLOSION CAN RESULT.

NEVER CHARGE A FROZEN BATTERY; IT CAN EXPLODE.

LEAD ACID BATTERIES CONTAIN SULFURIC ACID WHICH WILL DAMAGE EYES OR SKIN ON CONTACT. WHEN WORKING AROUND BATTERIES ALWAYS WEAR A FACE SHIELD TO AVOID ACID IN EYES. IF ACID CONTACTS EYES, FLUSH IMMEDIATELY EITHER CLEAR WATER AND

GET MEDICAL ATTENTION. WEAR RUBBER GLOVES AND PROTECTIVE CLOTHING TO KEEP ACID OFF SKIN. IF ACID CONTACTS SKIN, WASH OFF IMMEDIATELY WITH CLEAN WATER.

DISCONNECT THE BATTERY BEFORE WORKING ON THE ELECTRICAL SYSTEM. REMOVE THE GROUND TERMINAL FIRST. WHEN RECONNECTING THE BATTERY, RECONNECT THE GROUND TERMINAL LAST.

WHEN USING AN EXTRA BATTERY TO JUMP START AN ENGINE, BEFORE MAKE CONNECTIONS, YOU SHOULD BE SURE POLARITY OF BATTERY AND THE CORRECT CONNECTIONS. WHEN USING EXTRA BATTERY ALWAYS MAKE LAST CONNECTION TO ENGINE OR GROUND (NEVER AT BATTERY). WHEN REMOVING JUMP START CABLES, ALWAYS REMOVE CONNECTION FROM ENGINE OR GROUND FIRST.

FOLLOW MANUFACTURER'S DIRECTIONS FOR JUMP START OF ENGINES WITH AID OF EXTRA BATTERY. OPERATOR MUST BE AT A CONTROL STATION WHEN JUMP STARTING ENGINE SO THAT MACHINE WILL BE UNDER CONTROL WHEN ENGINE STARTS. JUMP STARTING IS A TWO-PERSON OPERATION.

Schematics

Section 8

8.1 General

This section contains schematics to be used for locating and correcting most of the operating problems which may develop.

8.2 Troubleshooting

It should be noted that there is no substitute for a thorough knowledge of the equipment and related systems.


It should be recognized that the majority of the problems arising in the machine will be centered in the hydraulic and electrical systems.


The first rule for troubleshooting any circuit that is hydraulically operated and electrically controlled is to determine if the circuit is lacking hydraulic oil and electrical control power. This can be ascertained by overriding the bypass valve (mechanically or electrically) so that oil is available to the function valve, then overriding the function valve mechanically. If the function performs satisfactorily, the problem exists with the control circuit.

8.3 Hydraulic Circuit Checks

The best place to begin the problem analysis is at the power source (pump). Once it is determined that the pump is serviceable, then a systematic check of the circuit components, beginning with the control, would follow. For aid in troubleshooting, refer to the **followed hydraulic schematics and Electric schematics.**

8.3.1 Hydraulic Schematics





8.3.2 Electric Schematics

